

ElectricalOM Getting Started

ElectricalOM



POWERFUL - INTELLIGENT - AUTOMATED

BS7671 - 18TH EDITION ELECTRICAL DESIGN & CERTIFICATION SOLUTION

Table of contents


Tutorial - Quick Start	5
Main Environment	5
Basic settings.....	6
Project info and options	6
Schematic environment	8
Navigating the schematic	9
Default Symbols	10
Creating New Symbols	11
Example Design	14
Example Details	15
Step 1 - Design the Main Structure of the Installation.....	17
Add and Edit the Main Supply	17
Add the Main Supply	17
Edit the Main Supply	18
Add the Main and Sub Distribution Boards.....	19
Add the Main Distribution Board	19
Add Sub Distribution Boards	20
Set the Circuit Description	21
Set the Board Ways and Style	23
Add Final Circuits	25
Add a Final Circuit.....	26
Edit the Final Circuit's Basic Information.....	27
Set the Description, the Kind and the Load Details.....	28
Display Calculation Errors and Recommendations	29
Apply Changes	30
Circuits Rearrangement.....	30
Copy / Paste.....	30
Drag / Drop.....	31
Shifting Circuits	33
Step 2 - Calculate the Maximum Demand and Apply Load Balancing	34
Apply Diversity Factors	34
Maximum Demand	35
Load Balancing	36
Step 3 - Set the Protective Devices and Calculate the Cable Sizes	39
Set the Protective Devices	39
Circuit Protection	39
Incomer Disconnection/Isolation.....	40
Use of RCD	41
Set the Cable Size	42
Minimum Conductor Sizes	42
Phase/Neutral Conductor	44
Circuit Protective Conductor (CPC)	45
Armour as CPC	47

Separate Conductor	48
Correction Factors	48
Step 4 - Resolve Calculation Warnings and Discrimination Problems.....	49
Circuit with Critical Errors	50
Voltage Drop Errors	51
Voltage Drop Limits	52
Protective Devices Discrimination Problems	53
Fixing Discrimination Problems	54
Step 5 - Finalize Design and Print Reports	56
Add Symbols to the Schematic.....	56
Show Calculations in Schematic	57
Create New Schematic Page	58
Set Page Size and Add Frames.....	59
Print and Export Results	60
Print Selected Circuit Report.....	61
Print Active Page of Schematic	61
Schematic Drawing Mode	63
Drawing Objects.....	63
Selecting Objects.....	64
Edit Commands	64
Undo Redo	67
Object Snaps.....	67
Object Properties.....	69
Ortho Mode.....	69
Pan.....	70
Calculations and Checks.....	70
Design Current and Current Carrying Capacity Calculations.....	70
Voltage Drop Calculation	71
Maximum Phase Fault Current Calculation	72
Minimum Phase Fault Current Calculation	73
Earth Fault Current Calculation.....	74
Protective Device Disconnection Time at Earth Fault.....	75
Calculation of Touch Voltage.....	76
Maximum Earth Fault Loop Impedance Calculation.....	76
Short-Circuit Maximum Peak Value for Busbar Trunking Systems	77
Transformer short circuit fault current calculation.....	78
References	78
Warnings Environment	78
Critical.....	79
Voltage Drop Check	80
Voltage Drop Within Final Circuit for a Private Supply.....	80
Touch Voltage Limit Check	81
Ring Sockets.....	82
Protective Device Rating Check.....	83
Ph/N Conductor C.S.A Check	84
RCD Device Required for Circuit Check	85
Maximum Permitted Disconnection Time at Earth Fault Check.....	86

CPC Adiabatic Check	87
Maximum Earth Fault Loop Impedance Check.....	88
Design Current and Current Carrying Capacity Checks	89
Phase Conductor Adiabatic Check	90
Busbar Trunking System Short-Circuit Peak Withstand Check.....	91
Ultimate Breaking Capacity of the Circuit's Protective Device Check.....	92
Ultimate Breaking Capacity of the Incomer Protective Device Check.....	92
Rating of the Incomer Switch/Isolator Check	93
Rating of the Incomer Overcurrent Protective Device Check	94
Neutral Conductor Current Carrying Capacity Check	94
Neutral Current Protective Device Rating Check	95
Motor Starter Overload Setting Check.....	96
UPS Power Rating Check	97
Transfer Switch Load Rating Check	98
Source Load Capacity Check	98
Source Earthing Conductor Adiabatic Check	99
Important	100
Voltage Drop over the Split Limit Set Check	101
Energy Based Discrimination Check.....	101
Discrimination During Overcurrent Check.....	102
Incomer Protective Device Discrimination During Overcurrent Check.....	103
Discrimination During Earth Fault Check	103
Incomer Protective Device Discrimination During Earth Fault Check	104
Motor Starting Check.....	104
Service Breaking Capacity of the Circuit Protective Device Check.....	105
Service Breaking Capacity of the Incomers Protective Device Check	106
Installation in Conduit Check	107
Installation in Trunking Check.....	107
Installation Compliance with Regulations Check	108
Harmonic Content in Circuit Check	109
Current Carrying Capacity of the Tails Conductor Check	110
Simple	111
Load Balance Check	111
Power Factor Correction Unit Usage Check	112
Existing Installation Warning.....	113
Inactive Circuit Warning	114

Tutorial - Quick Start

This tutorial is a quick start for users with little or no experience using the software. The purpose of the tutorial is to guide the user through the basic functionalities of the software so that they can be ready to start designing and studying low-voltage electrical installations of their own.



Main Environment

The main operating environment has a main menu, and areas for modeling, information and warnings.


1. Main Menu: From the main menu, the user has access to a number of project functions. These include opening or saving project files, configuring project settings, inserting circuits, managing windows, accessing the help section of the software or requesting support.

2. Tree Network View: In ElectricalOM, each electrical element of the active network appears in the tree network view, the left-most panel of the application window, allowing quick access and modifications to the active network. From the tree network view the user can add or delete circuits or modify the network structure by dragging and dropping element nodes.

3. Warnings: During the creation of a project, calculations and checks are performed automatically with detailed error messages that appear in the warnings area. The area for warnings notifies the user when the software has found the model to be out of compliance or not to satisfy a physical constraint of the installation material. Critical warnings require that the user go back and change project settings in order to put the project into compliance with regulation, or so that the project meet the physical constraints of the installation material. Elements with warnings appear in red in the tree network view.

4. Module Tabs: ElectricalOM is developed using modular software development principles, allowing add-on modules to be used to extend the features of the software on demand. The modules can be popped out, to be made to appear in a different window, allowing immediate access to information during modeling.

5. Active Module Area: The module corresponding to the active tab (4) appears in this area, allowing the user to perform tasks and modifications.



Basic settings

[Project Information and Main Options](#)

[Setting the Schematic Environment Settings](#)


[Navigating the Schematic: Pan, Zoom](#)

[Setting the Default Symbols](#)

[Creating New Symbols](#)

Project info and options

To configure the project from the main menu select **Edit (1)** and then **Project info and options... (2)**.



From the project information tab (1) the user can set a number of project attributes, including: the title of the project, the client, the date and also designer related information. The user may also choose to

include his or her logo by clicking the image below (2).

In case of multiple calculations scenarios the user may associate specific information with a particular scenario by describing the scenario or clicking the corresponding button (3). Project revisions (4) are also available for the user to keep track of the changes and modifications made during the project's implementation.

Project information, designer information, and the most recent revision will be displayed in the frame of each page of the schematic, and at the reports. These information are project related and should be set for every new project. The **Predefined** button (5) fills in the default user information (see below).

Project info and options

Project info | User default info | Checks | Program defaults

Project info

Project title: Project title...

Client: Client...

Date: 24/11/2016

Designer office info

Firm:

Engineer:

Logo: 

Reset

Predefined

Calculations scenario




Scenario: ...

Project revisions

Revision by	Revision date	Comments


Close

The default user information can be set from the default user information tab (1). Calculations related settings can be set from the checks tab (2) and default program options covering auto-save, language and color scheme from the project defaults tab (3). These settings are system-wide and are applied each time the software starts.



Schematic environment

You can set the schematic environment settings by clicking on the palette options icon (1). From the palette options dialog (2) that appears, the user can control the appearance of the schematic.



Navigating the schematic


Pan and Zoom are used to help the user navigate their view of the schematic in order that they can more easily examine circuits of interest. In general, panning and zooming the view are accomplished by using the mouse wheel. Rolling the wheel zooms the view, while pressing the wheel and dragging pans the view. Note that the position of the cursor will affect the way that the view responds to a zoom action.



Note:

If you use a touch pad, you can use gestures to pan and zoom.

- **Zoom in:** Glide thumb and index finger apart.
- **Zoom out:** Pinch thumb and index finger together.
- **Pan:** Use a two-finger swipe in the direction that you want to move the view.




From the schematic tool bar you can also perform zoom actions. To zoom to the extents of the figures in


the drawing press the **Zoom All** button (1). To zoom to a rectangular area of your specification, click the **Zoom Window** button (2) and then specify opposing corners of this area.

Default Symbols

To control which symbols are used to display devices in the schematic:


From the tool bar, click the default symbols icon(1). Make a selection from the appearing dialog by clicking on the device that you would like to configure. A dialog will appear, allowing you to choose a symbol for this device by selecting a category (3) and then double-clicking on the symbol of your choice.






Creating New Symbols

To create a new symbol, select the symbols tab (1) at the right panel of the schematic module. Then Right-click the symbols area list-box (2). Select **Create new...** (3) to open the symbol builder.




Using the symbol builder, you are able to create a symbol simply by drawing figures in the design area (2). The green cross indicates the insertion point of the symbol. The insertion point can be moved to a location of your choice.

From the general properties (3) you can set the default price (4) of the symbol, which is used in the Bill of Quantities Report. Each symbol can be placed in one of the categories (5), including Sources, Distribution Circuits, final circuits etc. A symbol name must be given (6) before saving (7).



To edit an existing symbol, select the symbols tab (1) at the right panel of the schematic module. You may filter the symbols appearing by selecting a category (2). To edit a symbol, right-click it and then choose **Edit symbol...**(3) to enter the symbol builder. You can also delete (4), rename (5) or move the symbol to another category (6).



Example Design

The design process is typically followed as in the steps described below.

Step 1 - Design the main structure of the installation:

At the beginning of the design process we create the basic structure of the installation. This means setting up the distribution circuits, and final circuits downstream from them. When a circuit is added to the installation, the designer sets the type of the conductor, its installation method and its length. For final circuits, the user need specify the type of circuit, along with all of its load parameters. These parameters include the kind, number of points, watts per point or design current, power factor, third harmonic percentage and any diversity factor.

Step 2 - Calculate the maximum demand (and apply load balancing for three phase installations)

After completing step one, the designer is able to calculate the load demand of each distribution circuit and the maximum demand of the installation by applying diversity factors. Also if required the user can specify any spare load percentage to be considered. In case of a three phase installation, at this stage it is appropriate to make changes for load balancing starting from the downstream sub distribution circuits, and moving upstream to the Main Distribution Circuit. The designer can balance the load by moving, swapping or shifting circuits in the distribution circuit so the loads per phase are balanced.

Step 3 - Set the protective devices and calculate the cable sizes

Knowing the demand of each circuit and the maximum demand of the installation, the designer is able to set the appropriate protective devices and then calculate the required cable sizes, starting from the Main Distribution Circuit and moving downstream. Also at this point the designer can set correction factors for the ambient temperature, depth of lay, etc., that eventually will affect the cable size selection.

Step 4 - Resolve warnings and discrimination problems

At this point the user must resolve the critical warnings, and give attention to and resolve warnings related to the discrimination between the protective devices.

Step 5 - Finalize design and print reports

To finalize the design the user may set the frame size per page and draw details or notes.

Example Details

In this tutorial we will design a three phase domestic installation. The installation consists of three distribution circuits, the Main Distribution Board and two sub distribution boards. The Main Distribution Board is located at the ground floor and feeds a sub distribution board to the basement and another to the floor level. The basic information required for the design are the Main Supply characteristics and the final circuits per distribution board. These are presented below:

Main supply characteristics:

Type: Three phase - Public supply

Voltage: 400V/230V, 50Hz

Earthing system: TN-C-S

Source rating: 500kVA with source impedance Z: 6%

Supply cable up to the origin of the installation:

- **Up to the building:** Al - Multicore XLPE 90oC armoured, length: 20m, cross sectional area: 16mm², installed underground
- **Up to the meter:** Al - Multicore XLPE 90oC armoured, length: 10m, cross sectional area: 16mm², installed on a surface

Distribution circuits:

Name	Supplied from	Phase	Cable length (m)	Cable type and installation method
Main: MDB	Main supply	Three phase	5	Cu - Multicore XLPE 90oC armoured, in underground single way ducts
Basement DB-	MDB	Single	10	Cu - Single Core PVC 70oC non-armoured, in

G		phase		conduit in a wall
Floor level DB-F	MDB	Single phase	10	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall

Main Distribution Board - MDB:

load kind	Installation points	Cable length (m)	Cable type and installation method
Cooker	1	15	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall
Dish washer	1	10	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall
Dryer	1	10	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall
Fridge	1	10	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall
Air conditioning 1	1	20	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall
Air conditioning 2	1	20	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall
Sockets ring	25	45	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall
Lights 1	15	30	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall
Lights 2	15	25	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall

Basement distribution board- DB-G:

load kind	Installation points	Cable length (m)	Cable type and installation method
Fridge	1	10	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall
Air conditioning	1	20	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall
Sockets ring	15	30	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall
Lights 1	10	25	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall
Lights 2	15	30	Cu - Single Core PVC 70oC non-armoured, in conduit in a wall

Floor level distribution board- DB-F:

load kind	Installation points	Cable length (m)	Cable type and installation method
Air conditioning 1	1	15	Single Core PVC 70oC non-armoured, in conduit in a wall
Air conditioning 2	1	15	Single Core PVC 70oC non-armoured, in conduit in a wall
Sockets ring	15	30	Single Core PVC 70oC non-armoured, in conduit in a wall
Lights 1	10	25	Single Core PVC 70oC non-armoured, in conduit in a wall

Step 1 - Design the Main Structure of the Installation

At the beginning of the design process we create the basic structure of the installation. This means setting up the distribution circuits, and final circuits downstream from them. When a circuit is added to the installation, the designer sets the type of the conductor, its installation method and its length. For final circuits, the user need specify the type of circuit, along with all of its load parameters. These parameters include the kind, number of points, watts per point or design current, power factor, third harmonic percentage and any diversity factor.

Add and Edit the Main Supply


The project begins with the creation of the Main Supply

[Add the Main Supply](#)

[Edit the Main Supply](#)


Add the Main Supply

To add the Main Supply, right click on the tree network view (1) or on the schematic view (2). From the design menu select **Insert, Source, 3Ph+N** to insert a three phase power source.



Edit the Main Supply

To edit the Main Supply, simply double click on it from the tree view, or select edit from the design menu, brought up by right clicking on the supply node, as shown below:



With the supply editor the user can set all of the properties of the installation up to the origin. These include the phase voltage, the earthing system and earthing arrangements, the supply frequency, the supplier's transformer rating, prospective fault current and external impedances, voltage drop settings, premises settings and touch voltage limit and other information specific to the supplier.

In our example we will set the values as shown below. Press **OK** to accept the changes.

Type: Public supply (1)


Voltage: 400V/230V (2) , 50Hz (4)

Earthing system: TN-C-S (3)

Source rating: 500kVA with source impedance Z: 6% (6)

Supply cable up to the origin of the installation: (7) and press "Set..." (8) to set the extra cable values.

- **Up to the building:** Al - Multicore XLPE 90oC armoured, length: 20m, cross sectional area: 16mm², installed underground
- **Up to the meter:** Al - Multicore XLPE 90oC armoured, length: 10m, cross sectional area: 16mm², installed on a surface



The resulted prospective symmetrical fault current at the origin is presented in 9 and prospective phase to N/Earth fault in 10. These values can be manually set if the user chooses not to set the extra cable up to the origin point of the installation (7)

[Add the Main and Sub Distribution Boards](#)

After adding the main supply we will add the main and sub distribution boards of the installation.


[Add the Main Distribution Board](#)

[Add Sub Distribution Boards](#)

Add the Main Distribution Board


To add the Main Distribution Board, left click on the Main Supply element (1) from the tree network view or the schematic view (2) and right click to show the design menu. From the design menu select **Insert**,

Distribution Board, 3Ph to insert a three phase Main Distribution Board.




Add Sub Distribution Boards

To add the first sub distribution board select the tree node labeled **[1.L1] empty** (1) with a left click and with a right click select **Insert, Distribution Board, 1Ph** (2).




Repeat to add the second sub distribution board from 1.L2.




Set the Circuit Description

You can set the description of the selected circuit from the properties tab (1), at the description field (2).



Alternatively you can set the description of the selected circuit from the tree network view by left clicking the circuit once, so that the selected node's text becomes editable. After editing the label press enter to apply the new description.




Set the Board Ways and Style

Board ways:


Initially the three-phase distribution boards have four ways, accommodating a total of 12 single phase circuits, and the single-phase distribution boards four single phase ways, accommodating a total of 4 single phase circuits. To increase the number of ways, select a distribution board from the tree network view or from the schematic, and from the properties tab, set the number of ways from the drop down menu (1).


In this tutorial we need to modify the ways of the sub distribution board DB-G, and increase them from 4 to 8 as shown below:




Board style:

Initially the style of the distribution board is Din Rail. To change the board's style select a distribution board element from the tree network view or from the schematic, and from the properties tab, click the button labeled **Select style...** (1). A pop-up window will appear, from which the style of the distribution board can be selected.





After selecting the style, the schematic will refresh to show the new distribution board, seen below (1). In this tutorial we will use a Din Rail style, so we undo the change by clicking the undo button (2).




Add Final Circuits

We will start by adding the final circuits to the Main Distribution Board and then continue with the final

circuits from the sub distribution boards.


[Add a Final Circuit](#)


[Edit the Final Circuit's Basic Information](#)



Add a Final Circuit


To add a final circuit at the position 1.L3, select the empty way in the tree network view (1) or at the schematic diagram (2) with a left click and then right click to show the design menu. From the design menu select **Insert, Final circuit 1Ph** (3).





Edit the Final Circuit's Basic Information


To edit the final circuit, select it from the tree network view (1) or from the schematic (2) with a left click on the symbol, and select the circuit edit tab (3).



Set the Description, the Kind and the Load Details


Here we are going to modify some of the parameters of a circuit from the circuit editor. To change the description of the circuit, we type the desired description into the text box labeled **Description** (1). We would like that the circuit be a cooker control unit, so we select the appropriate kind from the kind drop down menu (2). Default values for the load are automatically set according to the selected kind. To change this value, set the watts value (3) or the amperes value (4) in the corresponding field. For more detailed modeling, you can also specify the power factor (5), the third harmonic percentage (6) and the diversity factor (7). For this tutorial we will leave the default values unaffected.

Please note that the software performs calculations immediately, producing an error indication next to the offending parameter (8).




Display Calculation Errors and Recommendations

Calculations are made immediately following a change to the circuit editor, producing a graphical indication of an error next to the offending parameter. The error icons (1) in the circuit editor have a tool-tip that will present details about the corresponding error and a recommendation how to fix it (2). To display the tool-tip text the user need hover the mouse cursor over the error icon as shown below. At this stage we will not try to fix any of the errors. The errors will be fixed at a later stage after we have finished configuring the distribution circuits.



Apply Changes

To apply the changes and save the circuit press the **Apply changes** button (2). To cancel the changes press the **Cancel** button (3). To print the Calculations Report for this circuit press the **Print** button (4). If the tab belonging to the circuit editor (1) is marked with an asterisk, as in the screen shot below, it is an indication that the circuit has changes that have not been applied.



Circuits Rearrangement

In order to streamline design of a network, the user might find it helpful to copy and paste circuits and/or use other functions:


[Copy / Paste](#)

[Drag / Drop](#)


[Shifting Circuits](#)

Copy / Paste

Bellow we will copy the cooker circuit and paste it to 1.L2. To copy the circuit, select it from the tree network view or from the schematic diagram with a left click. Then with a right click on the selected circuit select **Copy**.




To paste the copied circuit, right click on empty way 1.L2 (1) and select **Paste** (2).




Drag / Drop

You can drag and drop circuits in order to move or copy them to another position anywhere in the active network tree. To do this, press down with the left mouse button on the element node (1) and keep the left mouse button pressed. Then move the mouse to desired position (2). Release the left mouse button to drop the circuit.




After dropping the circuit select **Replace, And Keep** to copy the circuit to the sub distribution board.



Shifting Circuits

To shift circuits, select the circuit **P1 COOKER** (1) with a left click and then right click to show the design menu. From the design menu select **Shift circuit, Down** (2). Alternatively you can use the shortcut keys **Ctrl+Shift+Down**.



Step 2 - Calculate the Maximum Demand and Apply Load Balancing

After completing step one, the designer is able to calculate the load demand of each distribution circuit and the maximum demand of the installation by applying diversity factors. Also if required the user can specify any spare load percentage to be considered. In case of a three phase installation, at this stage it is appropriate to make changes for load balancing starting from the downstream sub distribution circuits, and moving upstream to the Main Distribution Circuit. The designer can balance the load by moving, swapping or shifting circuits in the distribution circuit so the loads per phase are balanced.


[Apply Diversity Factors](#)

[Maximum Demand](#)


[Load Balancing](#)

[Apply Diversity Factors](#)

At this point we have completed the first step of the work flow. The next step is to calculate the maximum demand and apply load balancing. To do this we will first apply the default diversity factors for each distribution circuit. This can be done from **Circuit functions** after right clicking on the Main Supply as shown below. This will calculate the diversity factors for all final circuits.




We can also apply extra diversity per distribution circuit and set spare load from the circuit editor. For this tutorial we will apply an extra diversity factor of 0.9 (1) only for the Main Distribution Circuit as shown below:




Maximum Demand

From the loads tab (1), the loads summations results are displayed. The diversified plus spare load (2) of the Main Distribution Circuit, represents the maximum demand of the installation.



Load Balancing

In three-phase systems we need to make sure that the load is balanced across the phases. To check this we can filter the warnings to show only the simple ones by selecting **Simple** in the warnings type filter (1), and checking for load balance warnings (2). In our case the load in MDB is not balanced, so we need to examine the loads in each of the phases (3). From the loads chart we can see that L3 (gray) is less than the other two L1 (brown) and L2 (black).



A possible solution to the load balancing problem is to move a circuit from L2 (black) to L3 (gray) to increase the total in L3 and at the same time reduce it for L2. We right click on **Lights 2** and choosing to **Cut** (1), and then **Paste** (2), the circuit **Lights 2** is moved from 4.L2 to 4.L3 causing the load to be balanced and the load balance warning to be resolved (3).

ElectricalOM Getting Started

Properties Symbols Load Unit drop

NBC

Connected load		
kVA	Response	
10.3	10.2	
11.1	10.7	
11.1	10.7	
Total	43.3	

Diversified load		
kVA	Response	
12	10.2	
12.6	10.7	
12.6	10.7	
Total	32.4	

Diversified + Spare load		
kVA	Response	
12	10.2	
12.6	10.7	
12.6	10.7	
Total	32.4	

Warning: The load of NBC is not balanced. It is recommended to review the allocation of loads in each phase.

Properties Symbols Load Unit drop

NBC

Connected load		
kVA	Response	
10.3	10.2	
11.1	10.7	
11.1	10.7	
Total	41.3	

Diversified load		
kVA	Response	
12	10.2	
11.7	10.5	
11.7	10.5	
Total	31.5	

Diversified + Spare load		
kVA	Response	
12	10.2	
11.7	10.5	
11.7	10.5	
Total	31.5	

Warning: The load of NBC is not balanced. It is recommended to review the allocation of loads in each phase.

Properties Symbols Load Unit drop

NBC

Connected load		
kVA	Response	
10.3	10.2	
11.1	10.7	
11.1	10.7	
Total	43.3	

Diversified load		
kVA	Response	
12	10.2	
11.7	10.5	
11.7	10.5	
Total	32.4	

Diversified + Spare load		
kVA	Response	
12	10.2	
11.7	10.5	
11.7	10.5	
Total	32.4	

Warning: The load of NBC is not balanced. It is recommended to review the allocation of loads in each phase.

Step 3 - Set the Protective Devices and Calculate the Cable Sizes

Knowing the demand of each circuit and the maximum demand of the installation, the designer is able to set the appropriate protective devices and then calculate the required cable sizes, starting from the Main Distribution Circuit and moving downstream. Also at this point the designer can set correction factors for the ambient temperature, depth of lay, etc., that eventually will affect the cable size selection.

Set the Protective Devices

Here we will show how to set the main over-current protective device (the protective device of the Main Distribution Circuit) and the main incomer disconnector/isolator. Following the same procedure you can modify and set the protective devices of the sub distribution and final circuits.


Circuit Protection

Incomer Disconnection/Isolation

Use of RCD


Circuit Protection

From the circuit editor (1) select the protective devices tab (2) and then under the circuit protection tab (3) click the button labeled **Change...** (4) to make a selection from a table of manufacturers.




To select a protective device select the manufacturer (1), the type (2), the device family (3) and the device rating (4). Red colored ratings indicates that a particular rating selection is not acceptable because of the circuit's load. To submit the selection press the **Select** button (5).

To help you finding the desired device, you can click on the device-manufacturer icon (6) and also filter the results based on the device type (7) and ultimate breaking capacity, Icu (8) .




For the Main Distribution Circuit we will choose a 3-Pole MCB Type C 63A with Icu = 10kA as shown below:



Incomer Disconnection/Isolation


Incomer disconnection/isolation devices can be set only for distribution circuits. To set the incomer disconnection/isolation device, select the protective devices tab (1) and then the incomer disconnection/isolation sub-tab (2). The engineer can choose to use an overcurrent protection device and/or an RCD device and/or and isolation/disconnection device. For this example we will use the default isolation/disconnection device AC21 at 63A (3), as shown below.



Use of RCD

Where required the engineer can choose to use an RCD device by checking the corresponding box (1) and then by clicking the button labeled **Change...** (2) to select the protective device from a table of manufacturers. The user also can select the type of the RCD device from the list (3).

The screen shot below shows an example where an RCD is in use for a sockets circuit:



Set the Cable Size

After setting the protective device we are ready to calculate the cable size of the Main Distribution Circuit.

[Minimum Conductor Sizes](#)


[Phase/Neutral Conductor](#)

[Circuit Protective Conductor \(CPC\)](#)


[Correction Factors](#)

Minimum Conductor Sizes

In some cases it is required that the selected conductors are over a default minimum size. To set the minimum conductor sizes go to **Functions** from the main menu and choose **Minimum conductor sizes** (1).



From the minimum conductor sizes dialog the engineer can choose the minimum conductor size per circuit kind. In our example we have chosen 1.5mm² for all kinds of final circuit. To do this we select the circuit kind (1) and from the list (2) we choose the minimum size. Note that submitting the minimum conductor sizes does not affect existing circuits. The minimum sizes are applied to newly added circuits or after applying changes to existing ones, during circuit editing.



Phase/Neutral Conductor

To set the phase and neutral conductor, go to the phase/neutral conductor tab (1) of the circuit editor. From the conductor type menu (2), you can change the type of the conductor. The list is broken into a number of columns to help the user make a selection. The first column contains a reference to the corresponding conductor in the BS 7671. The second column presents the material of the conductor. The third column shows the description of the conductor and the fourth column indicates the armour or sheath material.

To filter the list of available conductors use the filtering options (3). The make-up of the conductor is shown below (4) the drop-down. Conductors can also accept special options (5).

For the Main Distribution Board we will select the second conductor type from the list, making its conductor a copper multicore 90oC XLPE armoured cable.

After selecting the type of conductor we must now set the installation method (7). The installation methods are categorized (6). In this example we will choose Method D No. 70, which corresponds to underground single way ducts. The description of the installation method (8) helps the user identify whether the selected installation method is the correct one.

Some installation methods require special care in order to keep in compliance with the regulations of BS 7671, because they require additional information. For example, the method that we have chosen incorporates ducts, so the user must include information about the conduit type and size (9).

Finally, we set the length (10) of the cable to 5m and the cable's cross sectional area / rating from the drop-down (11) to 16mm² / 75A. The **Find** button (12) helps the user find the minimum cable size required. *Please use this function with caution because it can select wrong sizes if the upstream circuits have not yet been finalized.*

The screenshot shows the 'Apply changes' dialog box in ElectricalOM. The 'Ph/N Conductor' tab is active. The 'Type' is set to '4E4 Cu Multicore 90°C XLPE armoured'. The 'Filter list' is set to 'Cu' with 'All insulations' and 'All kinds'. The 'Wiring' is '3Ph + N'. The 'Makeup of circuit conductors' is 'SwaXpe90/M/Cu 1x4Cx1.5mm² + E(armour)'. The 'Installation' category is 'In ground' and the method is 'Method D No. 70 - In underground single way ducts'. The 'Conduit' is 'Plastic' and 'Light' with a diameter of 16mm. The 'Length (m)' is 5. The 'C.S.A (mm²) / Rating' dropdown is open, showing a list of options from 1.5 to 365A. The 'Find' button is highlighted with a red circle. A warning message at the bottom indicates a critical error: 'There are errors in 'MDB'. Please edit the item 1) The current inequalities are not satisfied (Ib=52.2) 2) The protective device rating is lower than the Nennstrom (In=63)'. A red circle highlights the 'Find' button next to the 32A option.

At this stage note that all previous errors have been resolved and the error indications have disappeared. A new error (1) appears due to the conduit's not being large enough to accommodate the conductor after having selected a larger cable size. To take care of this, click the find button below the conduit diameter to select a 32mm conduit diameter.

The screenshot shows the 'Apply changes' dialog box in ElectricalOM. The 'Ph/N Conductor' tab is active. The 'Type' is set to '4E4 Cu Multicore 90°C XLPE armoured'. The 'Filter list' is set to 'Cu' with 'All insulations' and 'All kinds'. The 'Wiring' is '3Ph + N'. The 'Makeup of circuit conductors' is 'SwaXpe90/M/Cu 1x4Cx1.5mm² + E(armour)'. The 'Installation' category is 'In ground' and the method is 'Method D No. 70 - In underground single way ducts'. The 'Conduit' is 'Plastic' and 'Light' with a diameter of 16mm. The 'Length (m)' is 5. The 'C.S.A (mm²) / Rating' dropdown is set to '16 75A'. The 'Find' button is highlighted with a red circle. A tooltip message appears over the 'Find' button, stating: 'The conduit diameter is not enough Calculation is based on the IEE Guidance Note 1, Appendix A Recommendation: Revise the installation method'.

Circuit Protective Conductor (CPC)

[Armour as CPC](#)

[Separate Conductor](#)


Armour as CPC

To set the circuit protective conductor (CPC) of the circuit, choose the earthing tab (1). The properties of the CPC depend on the cable being passed. In our case, during the configuration of the circuit protective conductor, special settings are provided for armoured cable arrangements (2). The adiabatic check (3) indicates the minimum size of the CPC. For distribution circuits the engineer may choose to use extra local earthing to reinforce the earthing of the installation (4). For the Main Distribution Circuit we will choose the first option, **Cable armour**.

1

Ph/N Conductor | Earthing | Protective Devices | Correction Factors | Voltage Drop | Other

Only cable armour will be used as the CPC



Installation: Cable armour (2)

- Cable armour
- Separate conductor
- Core of the cable
- Cable armour and separate conductor
- Cable armour and core of the cable

Cable's armour C.S.A (mm²)

Cable's armour resistance (Ω)

Adiabatic check of CPC (3)


Total CPC C.S.A (mm ²)	16.08
Minimum CPC C.S.A (mm ²)	0.71

Local Earthing Use (4)

	R(Ω)	X(Ω)
Local Earthing Electrode Impedance	0.000	0.000
Other Local Earthing Impedances	0.000	0.000
Total Local Earthing Impedance	0.000	0.000


Separate Conductor

To set a separate conductor as the circuit protective conductor, select the earthing tab (1). Here the engineer can specify how the CPC will be installed (3) and the size of the CPC (4). When setting the CPC make sure that the earth fault adiabatic check (5) is satisfied. The image (2) shows a typical diagram of the CPC installation.



Correction Factors


Correction factors affect the cable size selection. The engineer must set the correct factors in order to make sure that the design is appropriate for the conditions of the installation. The correction factors can be set by choosing the correction factors tab (1) at the circuit editor. The image below shows an example where the ambient temperature correction factor (2) brings about a violation of a constraint (3). In this tutorial we will leave all correction factors to the default values.



Step 4 - Resolve Calculation Warnings and Discrimination Problems

After inserting and editing all the parameters of the installation the user must resolve warnings that have put the network out of compliance with regulation. The warnings can be examined from the warnings area (1) and can be filtered based on their importance (critical, important, simple) and/or the type (load, voltage drop, discrimination, other) (2). Warnings can be printed by clicking on the print button (3). An element that has a warning associated with it is marked in red (4) in the tree network view.


Extensive documentation about the warnings presented in ElectricalOM can be found in section ["ElectricalOM Calculations Warnings and Checks"](#)



Circuit with Critical Errors

When a selected circuit has critical errors, the circuit edit tab is marked with a red icon (1) indicating the error. A tool tip with the description of the critical error is present when the user hovers the mouse over the tab. All warnings are presented in the warnings area (2).


Even if in the circuit editor there are no critical warnings, the circuit might still be associated with critical warnings due to circuits upstream. In this example the voltage drop limit is affected by the conductor belonging to the Main Distribution Board, which has been left to its default size 1mm², causing high voltage drops in the downstream circuits. We will take care of this error when we set the Main Distribution Board's conductor.



Voltage Drop Errors

Voltage drop errors are displayed in the warnings area (1). By clicking on the warning the affected circuit is selected. Detailed voltage drop calculations are available for each circuit through the voltage drop tab (2). The voltage drop area displays the voltage drop from supply, from circuit and the total (3).


In our tutorial, the distribution circuit DB-G has a voltage drop warning because of the [split limit set](#). To take care of this and eliminate the warning we will increase its conductor size from 6mm² to 10mm². After applying the change to the circuit editor the warning disappears.



Voltage Drop Limits

The voltage drop limits are defined when [editing the Main Supply](#). The engineer may also alter the voltage drop limits of an individual circuit from the circuit editor under the voltage drop tab (1).

For distribution circuits there is an option to split the voltage drop limit between the distribution circuit and its final circuits. This split limit is not a regulation requirement but is set by the designer to warn him or her about circuits exceeding the specified voltage drop percentage value, allowing for finer control of the voltage drop across circuits. By default the split limit is enabled and this can be disabled by selecting the option **Without split of the voltage drop limit** (2). For this tutorial we will leave the split limit to 1.5% per phase of the distribution circuit and the remaining 3.5% to the connected final circuits (3).



Protective Devices Discrimination Problems

The purpose of discrimination is to disconnect only the faulty circuit from the distribution network while maintaining the upstream electrical installation active.

Discrimination can be either total or partial. Discrimination is said to be total if discrimination between the upstream and downstream protective devices is provided up to the value of the maximum prospective short-circuit current at the downstream protective device.



Protective devices discrimination problems are tricky to resolve and sometimes may require a change to the design parameters, eventually affecting the cost of the installation. In some cases the engineer may decide to skip some of the checks and accept that the design will contain discrimination problems. According to regulation, discrimination (or selectivity) is demanded when it is necessary to prevent danger or when it is required for proper functioning of the installation.

ElectricaOM performs discrimination checks between the time-amperes curves of the protective devices, where overlapping curves indicate a discrimination problem. When the manufacturer's energy-based discrimination data are available and the fault condition is causing operation of the protective device below 0.1 sec, the checks are performed based on the manufacturer's discrimination tables.

In this tutorial we are using generic protective devices.

The images below show two cases. The first is a successful discrimination study, with no overlapping between the curves. The second study fails, with the curves overlapping.

Fixing Discrimination Problems




Fixing Discrimination Problems

To resolve problems with discrimination the engineer must make sure that the time-current curves of the protective devices are not overlapping, or where manufacturer data are available, it can be done through the energy-based discrimination check. Please note that energy-based discrimination checks are performed only when the operating time of the device under study is less than 0.1 sec.

From the discrimination study module (1), the engineer can inspect the selected circuit's protective devices behavior against those of the circuits upstream. In this tutorial we have chosen a 63A Type C MCB


for the MDB (2) and a 40A Type C MCB for the DB-G (3). This arrangement is causing a discrimination problem due to the overlapping of their time-current curves.



To resolve the above problem we need to choose a larger device for the MDB. At this point the engineer needs to choose a suitable device. If we select a 125A Type C MCB to resolve the discrimination problem, it will lead to an increase in cable size from 16mm² to 70mm² for the Main Distribution Circuit, which is not a good design for a domestic installation.

An alternative path is to choose an adjustable MCCB device that will be adjusted so that its time-amperes curve will not overlap with the downstream device.

To do so, click in the legend area of the main MCB (1). The overload setting of the MCCB device adjusted to the rated current 80A ($I_r = 80A$), leads from a 16mm² to a 25mm² cable size for the Main Distribution Circuit, which is acceptable for a domestic installation.



Step 5 - Finalize Design and Print Reports

After taking care of the warnings and applying the required fixes we are ready to finalize the design by adding additional symbols and choosing to show calculation results on the schematic. Finally, for each of the pages of the schematic, the page size and frame adjustments should be configured before printing.

[Add Symbols to the Schematic](#)

[Show Calculations in Schematic](#)

[Create New Schematic Page](#)


[Set Page Size and Add Frames](#)

[Print and Export Results](#)


[Schematic Drawing Mode](#)

[Add Symbols to the Schematic](#)

The designer can choose to add symbols in any part of the network by dragging and dropping the symbol from the symbols area (1) to the desired location, until the tick mark appears (2). In this example we have added a meter symbol before the main protective device.




To modify the symbol's label, click the symbol so that it becomes green (1) and modify its properties from the properties area (2).




Show Calculations in Schematic

To show calculations in the schematic click the show calculations button (1) from the schematic tool bar.




Calculations are shown beside the circuit's description.




Create New Schematic Page

For larger networks, the user may find it helpful to arrange the schematic over a number of pages. To do this, left-click a distribution circuit (1) that you want to move to a new page, and right click to show the design menu. From **Schematic functions** select **Create page** (2). You can navigate through the pages from the pages drop-down menu (3).




To rename the page press the button immediately to the right (4) of the pages drop-down menu. From the pop-up window (2) the user changes the description of the active page.



Set Page Size and Add Frames


To define the active page size for printing the pages of the schematic, a choice must be made from the

corresponding drop-down menu (1). Also the designer may choose to show the page frame (2) that contains also all of the project information. To resize the frame use the track bar (3) so that the drawing fits into the frame.




Print and Export Results

From the reports tab (1) the designer can print calculations summaries and schematics together in one report. The list selection (2) let the user choose which type of output to include in the final report. After choosing the desired types, click the **Generate report** button (3) to create the report. The report can be exported to PDF or RTF format (4) for further editing.




Print Selected Circuit Report

To print the analytical calculations report of a circuit right click the circuit from the network tree or the schematic and choose **Print report (1)**.




Print Active Page of Schematic




To print the active page press the print button (1). This will show a print preview as in the screen shot

below. Also the user can export the report to PDF file.




You can also print a part of the active page or change some of the print settings by clicking the print with settings button (2). This will show a form with settings that can be configured as shown below:



Schematic Drawing Mode

The drawing mode enables the user to draw CAD entities including polylines, rectangles, circles and other figures in the pages of the schematic. Object Snaps, ortho mode and other CAD based functions are also supported during drawing.



To enable drawing mode, click the drawing mode button (1) from the schematic toolbar. Afterward, the drawing mode toolbar will appear (2) with the available tools for drawing. Users with experience in CAD software (like AutoCAD) will find this easy to follow because the drawing commands are very similar.

Drawing Objects

Objects appearing in the drawing are specified by their geometry.



1. Line

A line is specified by two points, the start point and the end point. Lines can be one segment or a series of connected segments, but each segment is a separate line object.

2. Polyline

This object is composed of line and arc (bulges) segments.

3. Rectangle

A rectangle is defined by two points: the upper left and the lower right corner.

4. Circle

A full circle is defined by its center point and its radius.

5. Ellipse

An ellipse is determined by its center, and major and minor axes.

6. Arc

A circular arc is defined by the center point, the radius, the start angle and the end angle. An arc is always drawn anti-clockwise from the start angle to the end angle. The start point and end point properties of an arc are calculated through the start angle, end angle and radius properties.

7. Text

Text can be added to the drawing. The point must be specified where the text will begin. Then the angle of rotation must be specified. After that actual text content can be specified.

8. Multiline

Two or more lines in one object.

Selecting Objects

When you run an edit command you have to select the objects that you want to edit.

There are a few ways to select objects:

- You can click one by one the objects you want to select.
- Crossing method. With this method you have to set a rectangle by setting the two opposite corners of the rectangle. Then all the objects that are included entirely in the rectangle or have an intersection point with the rectangle, will be selected.
- Window method. Similar to the crossing method, but only the objects that are included entirely in the rectangle will be selected.

Edit Commands

In order to edit designed objects, most often you will run the specified command and then select the objects you want to edit. The same procedure applies when you want to create new objects from one or more drawing objects.

Alternatively, you can choose first the objects and then run the command. However not every command accepts preselected objects. Also not every command accepts multiple selected objects.



Commands can be used to edit objects in your drawing. For example, you can split a line into two smaller

lines, delete a circle etc. The commands are the following:

1. Move

With the move command you can move one or more drawing objects. After selecting the objects or object, define two points that define the distance and the direction of the movement. The first point defines the beginning of the "movement vector" and the second the end of the vector.


2. Copy

With the copy command you can copy one or more objects of the drawing. The user must select the objects to copy, and then the user is prompted to select two points. These two points define the "copy vector" and can either belong to the selected objects or not. The first point specifies the beginning of the "copy vector" and the second point the end of it.

3. Rotate


With rotate command you can rotate one or more objects around a base point.

First you have to select the object or objects and then specify the base point. Then you have to select an angle in radians to rotate the object.



4. Mirror

Objects can be reflected about an axis defined by the user. First you have to select the objects you want to mirror. Then you have to set the axis, by setting the first point of mirror line and then the second. At this point you have to choose if the source objects will be deleted or not.




5. Scale

With scale command you can increase or decrease the size of one or more objects. First you have to select one or more objects. Then you have to pick one point, which is going to be the base point. Next step is to specify the scale factor.


6. Trim

First select the objects that define the cutting edges at which you want to trim an object and then the object. Objects that can be trimmed include arcs, circles, elliptical arcs, lines. Notice that the trim command does not function if the objects do not intersect. At the example below there are some lines that were trimmed.

before trim




after trim



7. Array

Creates multiple copies of objects in an array pattern. The patterns are rectangular array and the polar array. With the rectangular array you can create an array defined by a number of rows and columns of copies of the selected object. First you have to select the objects. Then you have to define number of rows and number of columns of the rectangle, the distance between rows and the distance between columns.


Rectangular array




8. Extend

With extend command you can extend lines, arcs, polylines until they intersect with some other object which is used as limit of the extension. First you have to select the objects that constitute the limits of the extension. Then you have to choose a point at an object that you want to extend. If the object you want to extend does not intersect with above objects then nothing will happen.

Before extend



After extending the objects



9. Text Edit

With this command, you can edit the text content of a text object.

10. Erase

With the erase command you can delete one or more objects of the drawing. If you want to erase multiple objects you have to execute the select method. After the erase command, the objects no longer exist in the document or in the collection they belonged to, however the objects still exist as deleted objects in memory. So with undo command you can get them back to the drawing.

Undo Redo



Drawing mode has its own local undo (1) redo (2) stack which is reset after leaving the drawing mode.


Object Snaps

An Object Snap (Osnap) specifies a snap point on some part of an object. An Osnap mode will remain active until you turn it off.




Each Osnap has its own symbol when it is active. The screenshots below show an example of the related Osnap:


1. **Endpoint:** The Endpoint Osnap snaps to the end points of lines and arcs and to polyline vertices. This is one of the most useful and commonly used Osnaps.




2. **Midpoint:** The Midpoint Osnap snaps to the mid points of lines and arcs and to the midpoint of polyline segments.




3. **Nearest:** The Nearest Osnap snaps to the nearest point on a drawing object. This Osnap is useful if you want to make sure that a picked point lies on a drawing object but you don't necessarily mind exactly where it is located.




4. **Perpendicular:** The Perpendicular Osnap snaps to a point which forms a perpendicular with the selected object.




5. **Intersection:** The Intersection Osnap snaps to the physical intersection of any two drawing objects (i.e. where lines, arcs or circles etc. cross each other) and to polyline vertices.




6. **Center:** The Center Osnap snaps to the centre of a circle, arc or polyline arc segment. The cursor must pass over the circumference of the circle or the arc so that the centre can be found.




7. **Quadrant:** The Quadrant Osnap snaps to one of the four circle quadrant points located at north, south, east and west or 90, 270, 0 and 180 degrees respectively.




8. **Node (point):** The Node Osnap snaps to the center of a Point object.



9. **Tangent:** The Tangent Osnap snaps to a tangent point on a circle. This Osnap works in two ways. You can either draw a line from a point to the tangent point or you can draw a line from a tangent point, the latter is referred to as the "Deferred Tangent" snap mode.




10. **Extension:** When the Extension Osnap is enabled and a user is passed over a line or arc temporary Osnaps are added that are used to get a point on the extension of those segments. If the extension of the two segments intersects, the user is getting the intersection of those segments. In particular, when the cursor passes over an entity then little crosses appear that indicate that the extension of this object is available. If the extension of a line or an arc is enabled (by passing the cursor over this object) then the user can move the cursor close to the extension of this object. At that time the extension line will appear providing also intersection extensions of multiple objects.



Object Properties

When selecting an object its properties appear at the properties tab. From the properties tab the user can change several properties of an object such as the line type, the pen color, the pen width etc. The screen shot below shows an example how to change the line type property of the selected line object.




Ortho Mode



A setting that limits pointing device input to horizontal or vertical. That means that if ortho mode is on and you want to draw for example one line, this line will be parallel to x or y axis.

Pan



With Pan command you can shift the location of your view. Also by pressing the mouse middle button activates the pan command. Like panning with a camera, pan does not change the location or magnification of objects on your drawing; it changes only the view. Pan command is a transparent command. Transparent commands are commands that can be invoked when another command is active.

Calculations and Checks

This section describes the major calculations with the corresponding checks performed by ElectricalOM Software:

[Design Current and Current Carrying Capacity Calculations](#)

[Voltage Drop Calculation](#)

[Maximum Phase Fault Current Calculation](#)

[Minimum Phase Fault Current Calculation](#)

[Earth Fault Current Calculation](#)

[Protective Device Disconnection Time at Earth Fault](#)

[Calculation of Touch Voltage](#)

[Maximum Earth Fault Loop Impedance \(maxZs\) Calculation](#)

[Transformer short circuit fault current calculation](#)

[References](#)

Design Current and Current Carrying Capacity Calculations

Design Current and Calculation of the Minimum Required Value of the Cable's Current Carrying Capacity
(I_b and min I_z)

Checks

$$I_b \leq I_n$$

$$\min I_z \leq I_t$$

General

$$\min I_z = \frac{I_n}{\text{CorrectionFactors}}$$

For ring socket circuit with In = 30A or 32A

$$\min I_z = \frac{20}{\text{CorrectionFactors}}$$

Ring socket circuits otherwise

With:

I_b

I_n

min I_z

the design current of the circuit under consideration in Amperes
 the nominal current or current rating of the protective device protecting the circuit against overcurrent in Amperes
 the minimum required value of the cable's current carrying capacity

$$\min I_z = \frac{I_n \cdot 0.625}{\text{CorrectionFactors}}$$

Grouped circuits not liable to simultaneous overload

$$\min I_z = \max \left\{ \frac{I_b}{C_g}, \sqrt{I_n^2 + 0.48 \cdot I_b \cdot \frac{1 - C_g^2}{C_g^2}} \right\}$$

General motor circuits

$$\min I_z = \frac{OL}{\text{CorrectionFactors}}$$

Star-Delta Motor Circuits

$$\min I_z = \frac{OL/\sqrt{3}}{\text{CorrectionFactors}}$$

With:

$$\text{CorrectionFactors} = C_a \cdot C_i \cdot C_g \cdot C_c \cdot C_d \cdot C_s \cdot C_h \cdot C_f$$

- I_b the design current of the circuit under consideration in Amperes
- I_n the nominal current or current setting of the protective device protecting the circuit against overcurrent in Amperes
- $\min I_z$ the minimum required value of the cable's current carrying capacity

- I_t the value of current tabulated in cable tables
- C_a Correction factor for ambient temperature
- C_i Correction factor for thermal insulation
- C_g Correction factor for grouping
- C_f Correction factor for using BS3036
- C_c Correction factor for ground installations
- C_d Correction factor for underground installation depth
- C_s Correction factor for ground soil thermal resistivity
- C_h Correction factor for triple harmonic currents
- OL Motor starter overload. By default $OL = I_b$

Busbar Trunking System notes: With protection using a gG (gl) fuse an additional correction factor, equal to 1.1, is used. Note that using gl fuses for protection means reducing the busbar trunking's allowable current.

Voltage Drop Calculation

Voltage Drop Calculation (V_d)

For single phase circuits:

$$\frac{I_b \cdot (C_t \cdot \cos \varphi \cdot \langle mV/A/m \rangle_r + \sin \varphi \cdot \langle mV/A/m \rangle_x) \cdot L}{1000}$$

For three phase circuits:

Voltage Drop Limits Check

The software checks that the total voltage drop (between the origin of the installation and the circuit) is in the voltage drop limit set.


The voltage drop limits can be user defined or according to Table 4Ab in Appendix 4 of BS7671.

$$\frac{I_b \cdot \left(C_t \cdot \cos \varphi \cdot \frac{\langle mV/A/m \rangle_r}{\sqrt{3}} + \sin \varphi \cdot \frac{\langle mV/A/m \rangle_x}{\sqrt{3}} \right) \cdot L}{1000}$$

With:

- I_b the design current of the circuit under consideration in Amperes
- $\langle mV/A/m \rangle_x$ the tabulated resistance/reactance of the conductor taken from the tables 4D1B–4J4B of BS 7671
- $\cos \varphi$ the power factor of the load of the circuit
- C_t the temperature correction factor (according to BS 7671 Appendix 4)
- L the circuit length in meters

Note: For unbalanced 3 phase circuits, current will be flowing in the neutral conductor as illustrated in the phasor diagram below. The voltage drop in each phase is calculated by summing of the vectors of the phase and the neutral voltage drops.



Maximum Phase Fault Current Calculation

Maximum Phase Fault Current Calculation ($max I_{sc}$)

The total impedance is the sum of the impedances of the conductors from the origin of the installation to the circuit under consideration. For single phase circuits, the maximum fault current is between the phase and the neutral and in three phase circuits it is when all phases are shorted (symmetrical current). The total impedance is that with operating temperature 20°C (lower temperature means lower resistance).

In particular:

For single phase circuits:

Protective Device Breaking Capacity Check

The software acts according to regulation (434.5.1), to check the Breaking Capacity of the protective device:

$$I_{cu} > max I_{sc}$$

$$I_{sc} = \frac{C_{max} \cdot U_{ph}}{Z_e + Z_1^{20^\circ C} + Z_N^{20^\circ C}}$$

For three phase circuits:

$$I_{sc} = \frac{C_{max} \cdot U_{ph}}{Z_e + Z_1^{20^\circ C}}$$

With:

U_{ph}	the phase to neutral voltage
$Z_x^{20^\circ C}$	the impedance corrected at 20 oC
Z_1	the impedance of the phase conductor
Z_N	the impedance of the neutral conductor
Z_e	the external impedance (from the starting point of the circuit up to the origin of the installation)
C_{max}	The voltage factor Cmax is to take into account the worst case voltage variations conditions in a low voltage installation, specified in BS EN 60909 as 1.1 (optional factor)

Minimum Phase Fault Current Calculation

Minimum Phase Fault Current Calculation (*min I_{sc}*)

The type of the circuit will determine how the minimum phase fault current will be calculated. It is done according to IET Electrical Guidance Note 1, using the factors in Table E2 to calculate the maximum impedance of the conductor.

Single phase circuits:

$$I_{sc} = \frac{C_{min} \cdot U_{ph}}{Z_e + Z_1 + Z_N}$$

Three phase and Neutral circuits:

$$I_{sc} = \frac{C_{min} \cdot U_{ph}}{Z_e + Z_1 + Z_N}$$

Three phase (without neutral) circuits:

Adiabatic Check of the Phase Conductor During Phase Fault

The Software acts according to regulation (434.5.2), in order make the adiabatic check i.e whether or not the heat energy (I^2t) flowing during the time taken for the protective device to trip, exceeds the conductor withstand (k^2S^2).

$$t = \frac{k^2 \cdot S^2}{I^2}$$

With:

t	the maximum permissible disconnection time in seconds
k	the cable factor
S	the cross sectional area of the conductor mm ²
I	the minimum phase fault current

$$I_{sc} = \frac{C_{min} \cdot U_{ph-ph}}{2 \cdot (Z_e + Z_1)}$$

With:

- U_{ph} the phase to neutral voltage
 - U_{ph-ph} the phase to phase voltage
 - Z_1 the impedance of the phase conductor
 - Z_N the impedance of the neutral conductor
 - Z_e the external impedance
- The voltage factor Cmin is to take into account the worst case voltage variations conditions in a low voltage installation, specified in BS EN 60909 as 0.95 (optional factor)

C_{min}

The software compares the maximum permissible disconnection time with the time taken from the time-current curve of the protective device at the phase fault to find if the adiabatic check stands.

Note: For disconnection times less than 0.1 sec, the software checks for available Let-Through energy characteristics of the protective device at the calculated fault current and uses them during the adiabatic check.

Earth Fault Current Calculation

-Earth Fault Current Calculation (I_{ef})

TT Earthing System:

$$I_{ef} = \frac{C_{min} \cdot U_{ph}}{Z_d + Z_a + Z_1 + Z_2}$$

With:

- U_{ph} the phase to neutral voltage
 - Z_d the impedance of the supply
 - Z_a the impedance of the earthing electrode
 - Z_1 the impedance of the phase conductor
 - Z_2 the impedance of the CPC
- The voltage factor Cmin is to take into account the worst case voltage variations conditions in a low voltage installation, specified in IEC 60909 as 0.95

C_{min}

Adiabatic Check of the Protective Conductor During Earth Fault

The software, in accordance with regulation (543.1.3), makes use of the earth fault current, together with the operating time that has been found from the time-current curve of the protective device, in order to obtain a lower bound on the cross-sectional area of the protective conductor (CPC):

$$S_{min} = \frac{\sqrt{I^2 \cdot t}}{k}$$

With:

- S_{min} the minimum cross-section of the protective conductor
- k the cable factor

If the operating time is less than 0.1 sec, then

- I^2t Is the let-through energy characteristic of the protective device

TN Earthing Systems:

$$I_{ef} = \frac{C_{min} \cdot U_{ph}}{Z_e + Z_1 + Z_2}$$

With:

U_{ph} the phase to neutral voltage

Z_e the exterior impedance

Z_1 the impedance of the phase conductor

Z_2 the impedance of the protective CPC

C_{min} The voltage factor Cmin is to take into account the worst case voltage variations conditions in a low voltage installation, specified in IEC 60909 as 0.95

Otherwise,

I is the earth fault current
 t is the operating time of the time-current curve of the protective device

Note: If the protective device is an RCD or RCCB, then the software makes the check using for t the operating time of the RCD or RCCB.

Note: Impedances under fault conditions are calculated in accordance with Guidance Note 1: Table E2.


Protective Device Disconnection Time at Earth Fault

Protective Device Disconnection Time in the Event of Earth Fault

The maximum permitted disconnection time in the event of earth fault is determined by the time-current curve of the protective device. This can be examined in detail in the Discrimination Study Module, shown below:

Maximum Permitted Disconnection Time in the Event of Earth Fault

The maximum permitted disconnection time during earth fault is compared to the disconnection time calculated during earth fault.



Calculation of Touch Voltage

Calculation of the Touch Voltage Limit (U_t)

TT Earthing System, with RCD:

$$U_T = I_{\Delta N} \cdot Z_A$$

TT Earthing System, without RCD:

$$U_T = I_a \cdot Z_s$$

TN Earthing Systems:

$$U_T = I_{\Delta N} \cdot Z_s$$

With:

$$Z_A = Z_a + Z_2$$

$$Z_s = Z_e + Z_1 + Z_2$$

And with:

- $I_{\Delta N}$ the nominal sensitivity of the RCD
- I_a the current causing the operation of the protective device at the maximum time threshold
- Z_e the external impedance
- Z_a the impedance of the earthing electrode
- Z_1 the impedance of the phase conductor
- Z_2 the impedance of the protective conductor

Verification of the Touch Voltage Limit

The software, in accordance with regulation 411.5.3, verifies that the touch voltage does not surpass the allowable limit:

$$U_t \leq \max U_t$$

Where:

$\max U_t$ is the maximum touch voltage been defined by the user

Note:

$\max Z_A$ For TT earthing system, the software calculates this value in order to check for touch voltage.

Note:

Z_A is usually identified with R_A

$$Z_A = Z_a + Z_2$$

The value of Z_A is verified that is less than 200 Ω , as recommended in the ON SITE GUIDE, Section 10.3.5.

Maximum Earth Fault Loop Impedance Calculation

Maximum Earth Fault Loop Impedance Calculation ($\max Z_s$)

The calculation of $\max Z_s$ is made in order to verify that the protective device functions within time limits during earth fault.

The maximum impedance during earth fault, $\max Z_s$, is calculated from the time-current curve of the protective device.

After the user has defined the protective device's operating time limits during earth fault, the software finds from the time-current curve of the protective device the corresponding current $I_{\max Z_s}$, and calculates $\max Z_s$, as below:

Maximum Earth Fault Loop Impedance Check


$$Z_s \leq \max Z_s$$

with:

$$Z_s = Z_e + Z_1 + Z_2$$

where

- Z_e the external impedance
- Z_1 the impedance of the phase conductor,
- Z_2 the impedance of the protective conductor.



Note: For TT Systems Z_s includes also the impedance of the earthing electrode.

$$maxZ_s = \frac{U_o \times C_{min}}{I_{maxZ_s}}$$

where:

- U_o The nominal ac rms line voltage to Earth in volts (V) ,
- C_{min} The minimum voltage factor to take account of voltage variations. $C_{min} = 0.95$
- I_{maxZ_s} The current causing the operation of the protective device at the maximum time threshold, calculated from the time-current curve of the device.

Short-Circuit Maximum Peak Value for Busbar Trunking Systems

Short-circuit Maximum Peak Value for Busbar Trunking Systems

The permissible peak current, peak I , of the Busbar Trunking System must be greater than the peak value of the assumed asymmetrical short-circuit current, $I_{sc, asymm}$.

The value of the asymmetrical short-circuit current is obtained from the value of the symmetrical short-circuit current, I_{sc} , multiplied by a standardized asymmetry factor (k).

The first value of the 1st short-circuit asymmetry peak in the transient state is the one that is taken into account.

Standardized table for calculating the asymmetrical short-circuit

Isc: assumed symmetrical short-circuit kA (rms value)	Assymetric factor k
4.5 ≤ I ≤ 6	1.5
6 < I ≤ 10	1.7
10 < I ≤ 20	2.0
20 < I ≤ 50	2.1
50 < I	2.2

Reference: Coordination and protection of busbar distribution - Schneider Electric

Transformer short circuit fault current calculation

The transformer fault level calculator assumes that the transformer is supplied from an infinite bus. In other words, the fault level on the primary side of the transformer is considered to be infinite. Note that this assumption will give the worse case fault level on the secondary side of the transformer, which is sufficient for sizing of equipment according to fault rating.

Parameters:

- **Transformer rating (S):** Rating in kVA.
- **Voltage rating (V):** Voltage rating of the secondary windings.
- **Impedance (Z%):** Per-unit impedance of the transformer in %. Typically 4% to 10%.

The transformer short circuit current is calculated as follows:

$$I_p \text{ (kA)} = (S \times 100) / (\sqrt{3} \times V \times Z\%)$$

References

References

1. BS 7671
2. IET on Site Guide BS 7671
3. IET Electrical Guidance Notes 1-8
4. IET ELECTRICAL INSTALLATION DESIGN GUIDE 3rd Edition
5. CENELEC - TR 50480

Warnings Environment

Problems with the current implementation of the model are indicated in the Warnings Environment.

The warnings environment can be filtered easily, so that the engineer can focus on warnings of a particular type, or so that only the warnings associated with the selected circuit appear. The environment gives the user the option of filtering warnings by severity (critical, important, simple) (3) and/or the type (load, voltage drop, discrimination, other) (4). The user can choose to display only the warnings associated with the node that is selected in the tree view, by clicking on the **Selected element only** (5) option.

The total number of warnings is given by (1). The total number of critical warnings is given by (2).

Each of the warnings appearing in the list (7) indicates the originating circuit, the severity of the problem, and is accompanied by a brief description. With a double-click on a particular warning the user is brought to the configuration of the originating circuit to make changes and resolve the problem. Also the engineer is able to print the warnings list by clicking the **Print** button (6). Note that an element that has a warning associated with it is marked in red in the tree network view.

Warnings are grouped into three severity categories: Critical, Important and Simple.

[Critical](#)

[Important](#)

[Simple](#)

Critical

Critical warnings are those that have to be resolved. The user will not be able to move forward to the completion of the study if critical warnings are outstanding. These warnings have primarily to do with errors found by checks to the model, and for project configurations out of compliance with regulation.

[Voltage Drop Check](#)

[Voltage Drop Within Final Circuit for a Private Supply](#)

[Touch Voltage Limit Check](#)

[Ring Sockets Check](#)

[RCD Device Required for Circuit Check](#)

[Maximum Permitted Disconnection Time at Earth Fault Check](#)

[CPC Adiabatic Check](#)

[Maximum Earth Fault Loop Impedance Check](#)

[Design Current and Current Carrying Capacity Checks](#)

[Phase Conductor Adiabatic Check](#)

[Busbar Trunking System Short-Circuit Peak Withstand Check](#)

[Ultimate Breaking Capacity of the Circuit's Protective Device Check](#)

[Ultimate Breaking Capacity of the Incomer Protective Device Check](#)

[Rating of the Incomer Switch/Isolator Check](#)

[Rating of the Incomer Overcurrent Protective Device Check](#)

[Neutral Conductor Current Carrying Capacity Check](#)

[Neutral Current Protective Device Rating Check](#)

[Motor Starter Overload Check](#)

[UPS Power Rating Check](#)

[Transfer Switch Load Rating Check](#)

[Source Load Capacity Check](#)


[Source Earthing Conductor Adiabatic Check](#)

Voltage Drop Check

Voltage drop warnings will appear when the voltage drop between the Main Supply and a downstream circuit exceeds the voltage drop limit. To correct the problem, reconsider the cable sizes of the offending circuit, or the cable sizes of circuits upstream from it. Values that affect the voltage drop calculation are the design current (I_b), the circuit length and the cable size. The power factor and other correction factors such as circuit grouping and ambient temperature also take part in the voltage drop calculation. Note that you can change the voltage drop limit for each circuit under the **Volt drop** tab in the circuit editor.

[See the Voltage drop calculations](#)

To examine the voltage drop calculations go to the Volt drop tab at the properties area as shown below:



Voltage Drop Within Final Circuit for a Private Supply

When the voltage drop limits selected during the main source editing are for a private low voltage supply, the software checks the voltage drop within a final circuit according to Table 4Ab in Appendix 4 of BS7671:2008 + A3:2015.

The screenshot displays the 'Apply changes' dialog box in the ElectricalOM software. The 'Voltage Drop within circuit L1' is highlighted with a red circle and a warning icon, indicating a value of 12.85 V (5.59%). The interface includes various input fields for supply, load, and conductor properties, as well as a detailed installation method section.

Warnings: 1/2 Critical: 2 All

Item	Type	Warning
DB 1 -> Final circuit	Critical	The voltage drop within the final circuit 'Final circuit' is over the limit set (5% = 11.5V) per phase for the circuits of a private supply


Touch Voltage Limit Check

The touch voltage is used to determine the magnitude of the voltage to which the person at risk would be subjected in the event of an earth fault occurring in an installation. By assuming values of body resistance, the touch voltage concept can be extended to give an indication of the severity of the electric shock that could be experienced by that person.

The connection of all exposed- and extraneous-conductive-parts, either directly or indirectly, to a common terminal, i.e. the main earthing terminal of the installation, leads to the creation of touch voltages in the event of an earth fault and hence to the shock risk. In a correctly designed and erected electrical installation such a shock risk is not eliminated. Where the protective measure is automatic disconnection of supply then in the event of an earth fault, the speed of disconnection should be such that should the person at risk experience an electric shock it will not be a harmful one.

In order to resolve touch voltage warnings, it is recommended that the engineer revise the CPC or the protective device. It is also recommended that the user make sure that the upstream circuits have been set correctly.

[See the touch voltage calculations](#)



Warnings: 1/19	Critical: 13	All	Calculations	Load	Voltage drop	Discrimination	Other	Selected element only	Print
...	Item	Type	Warning						
...	MDB -> DB-G	Critical	There are errors in DB-G. Please edit the circuit. 1) Touch voltage over the maximum limit (TouchV = 25.04 < TouchV limit = 25) 2) RA=50.0757Ω is greater than the maximum RA limit maxRA=50Ω						


Ring Sockets

For ring sockets, special check settings that consider the cross sectional area of the phase and neutral conductor and the protective device rating are applied by default. The designer can omit these checks through the project info and options, under the **Checks** tab, as shown below.

Checks related to ring socket circuits:

[Protective device rating check](#)

[Ph/N conductor C.S.A check](#)




Protective Device Rating Check

Ring sockets require 30A or 32A protective device. To bypass the check and accept any rating see the [ring sockets check options](#).

Recommendation to resolve the error:

Use a 30A or 32A protective device.



Warnings: 1/20 Critical: 14 All

Item	Type	Warning
DB-G -> S1 RING	Critical	There are errors in 'DB-G -> S1 RING'. Please edit the circuit. 1) Ring Sockets - Protective device rating. Use an overcurrent protective device with rating 30A or 32A

Ph/N Conductor C.S.A Check

Ring sockets require 2.5mm² phase conductor (or 1.5mm² for MICC). To bypass the check and accept any rating see the [ring sockets check options](#).

Recommendation to resolve the error:

Use a 2.5mm² phase conductor (or 1.5mm² for MICC).

The screenshot shows the ElectricalOM software interface. On the left is a tree view of the supply system, including DB-G, DB-F, and various loads like lights, cookers, and fridges. The main window displays the 'Apply changes' dialog for a 'S1 RING' circuit. It shows load details such as 'Watts of a point: 200', 'Amps/Phase of a point: 0.87', and 'Voltage Drop of this circuit L1: 2.67 V (1.16%)'. A warning icon is present in the bottom right of the dialog, pointing to a table of conductor specifications. The table shows a discrepancy between the required C.S.A and the actual rating.

C.S.A (mm²) / Rating	1.5	17.5A
The phase conductor must have C.S.A 2.5mm² (1.5mm² for MICC) or greater		
Recommendation: Revise the phase conductor C.S.A		

Below the dialog, a warning message is displayed in a blue box: 'Warnings: 1/20 Critical: 14 All'. The warning text reads: 'There are errors in DB-G -> S1 RING: Please edit the circuit. 1) Ring Sockets - Ph/N conductor C.S.A = 1.5mm² < ring minimum = 2.5mm². 2) The current inequalities are not satisfied (Ib=13.04 < In=30, min Iz=20 < It=17.5)'. A red box highlights this warning message in the screenshot.

RCD Device Required for Circuit Check

For RCD use, BS7671 states the following regulation:

411.3.3 Additional protection.

In alternating current systems, additional protection by means of an RCD in accordance with Regulation 415.1 shall be provided for:

- (i) socket-outlets with a rated current not exceeding 20 A, and
- (ii) mobile equipment with a current rating not exceeding 32 A for use outdoors.

An exception to (i) is permitted:

- (a) where, other than for an installation in a dwelling, a documented risk assessment determines that the RCD protection is not necessary, or
- (b) for a specific labelled or otherwise suitably identified socket-outlet provided for connection of a particular item of equipment.

NOTE 1: See also Regulations 314.1(iv) and 531.2.4 concerning the avoidance of unwanted tripping.

NOTE 2: The requirements of Regulation 411.3.3 do not apply to FELV systems according to Regulation 411.7 or reduced low voltage systems according to Regulation 411.8.

NOTE 3: See Appendix 2, Item 10 with respect to risk assessment.

The screenshot shows the 'Apply changes' dialog box in ElectricalOM. The 'RCD / Earth fault protection' checkbox is unchecked, which has triggered a warning. A red circle highlights this checkbox, and a red arrow points to a detailed regulatory reference window for Regulation 411.3.3. The window text reads: '411.3.3 Additional protection. In a.c. systems, additional protection by means of an RCD in accordance with Regulation 415.1 shall be provided for: (i) socket-outlets with a rated current not exceeding 20 A, and (ii) mobile equipment with a current rating not exceeding 32 A for use outdoors. An exception to (i) is permitted: (a) where, other than for an installation in a dwelling, a documented risk assessment determines that the RCD protection is not necessary, or (b) for a specific labelled or otherwise suitably identified socket-outlet provided for connection of a particular item of equipment. NOTE 1: See also Regulations 314.1(iv) and 531.2.4 concerning the avoidance of unwanted tripping. NOTE 2: The requirements of Regulation 411.3.3 do not apply to FELV systems according to Regulation 411.7 or reduced low voltage systems according to Regulation 411.8. NOTE 3: See Appendix 2, item 10 in respect of risk assessment.'

Warnings: 1/20 Critical: 14 All

Item	Type	Warning
DB-G -> S1 RING	Critical	There are errors in 'DB-G -> S1 RING'. Please edit the circuit. 1) RCD / Earth fault device required for Switch socket outlet ring circuit

Maximum Permitted Disconnection Time at Earth Fault Check

The software checks that the protective device operates within the maximum permitted disconnection time in the event of an earth fault.

Recommendation to resolve the error:

Revise the CPC or the protective device. Also make sure the upstream circuits have been set correctly.

[See Protective device disconnection time at Earth Fault](#)

The screenshot displays the ElectricalOM software interface. On the left is a tree view of a circuit diagram with various components like DB-G, DB-F, and various appliances. The main panel is titled 'Apply changes' and contains several sub-sections:

- Load:** Shows kVA/phase (12.01, 11.69, 8.65), Diversity (0.90), cosφ (1), and 3rd Harmonics (%).
- Voltage Drop:** Shows voltage drops for circuits L1, L2, and L3, along with neutral current (13.96 A) and total load (32 kVA).
- Earth Fault:** Shows fault current (I_{ef} = 0.4525 kA), fault current (I_a = 630 A), and earth impedance (Z_e = 0.46 Ω).
- Disconnection Time (sec):** A table with columns for MCB, Maximum, Z_e(Ω), and max Z_e(Ω). The values are 7.4, 5, 0.829, and 0.3468 respectively. Red warning icons are present next to the 5 and 0.829 values.

A tooltip is visible over the 0.829 value, stating: "The disconnection time of the protective device is greater than the maximum disconnection time set. Recommendation: Revise the protective device or the conductor."

The warning panel shows the following details:

- Warnings: 1/11 (Critical: 2)
- Item: Supply -> MDB
- Type: Critical
- Warning: There are errors in 'MDB'. Please edit the circuit.
 - 1) Z_e=0.4829Ω is greater than the maximum Z_e limit maxZ_e=0.3468Ω
 - 2) Device disconnection time at earth fault

CPC Adiabatic Check

The software checks that the cross sectional area of the protective conductor is large enough that the protective device functions within time limits in the event of an earth fault.

[See Earth Fault Current Calculation](#)

Recommendation to resolve the error:

Revise the CPC or the protective device. Also make sure the upstream circuits have been set correctly.

The screenshot shows the 'Apply changes' dialog in the software. The 'Warnings' section at the bottom indicates a critical error: '1) CPC adiabatic check error (cpc = 1.5 mm² < Adiabatic check min cpc required = 4.1 mm²)'. The dialog also shows a table for 'Voltage Drop of this circuit' and 'Earth Fault' parameters.

Circuit	Voltage Drop (V)	%	Neutral current (A)
L1	0.39	0.17%	13.96
L2	0.37	0.16%	
L3	0.15	0.06%	32

Parameter	Value	Limit
Phase fault max I _{sc} (kA)	0.9807	1
Phase fault min I _{sc} (kA)	0.4877	0.23
Earth fault I _{ef} (kA)	0.4116	
Earth fault I _s (A)	332.57	
Earth fault Z _e (Ω)	0.46	
Fuse Disconnection Time (sec)	2.03	5
Fuse Maximum Z _s (Ω)	0.5309	0.657

Item	Type	Warning
Supply -> MDB	Critical	There are errors in 'MDB'. Please edit the circuit. 1) CPC adiabatic check error (cpc = 1.5 mm ² < Adiabatic check min cpc required = 4.1 mm ²)

Maximum Earth Fault Loop Impedance Check

The software calculates the maximum loop impedance to check that the protective device functions within time limits in the event of an earth fault.

[See Maximum Earth Fault Loop Impedance \(max Z_s\) Calculation](#)

Recommendation to resolve the error:

Revise the protective device, Z₁ (impedance of the phase conductor), Z₂ (impedance of the CPC). Also make sure the upstream circuits have been set correctly.

The screenshot displays the ElectricalOM software interface. On the left is a tree view of the circuit components, including DB-G, DB-F, and various lighting and appliance loads. The central panel, titled 'Apply changes', shows load details (kVA/phase: 12.01, 11.69, 0.65) and voltage drop calculations for three phases. The right panel is for selecting a separate CPC conductor, showing a calculated CPC C.S.A. of 1.5 mm² and a minimum required CPC C.S.A. of 8.55 mm². A warning box at the bottom states: 'The Zs impedance (0.5289Ω) is over the limit (0.4714Ω)'. Below this, a table lists warnings:

Item	Type	Warning
Supply -> MDB	Critical	There are errors in 'MDB'. Please edit the circuit. 1) CPC adiabatic check error (cpc = 1.5 mm² < Adiabatic check min cpc required = 8.53mm²) 2) Zs=0.5309Ω is greater than the maximum Zs limit maxZs=0.4714Ω 4) The current inequalities are not satisfied (lb=52.2 < ln= 80, minlz=88.89 < lt=75)

Warnings: 1/7 Critical: 2 All Calculations Load Voltage drop Discrimination Other Selected element only Print

Item	Type	Warning
Supply -> MDB	Critical	There are errors in 'MDB'. Please edit the circuit. 2) Zs=0.5309Ω is greater than the maximum Zs limit maxZs=0.4714Ω 4) The current inequalities are not satisfied (lb=52.2 < ln= 80, minlz=88.89 < lt=75)

Design Current and Current Carrying Capacity Checks

The software checks that the phase conductor has a current carrying capacity not less than the design current.

[See the Design Current and Current Carrying Capacity Calculations](#)

Recommendation to resolve the error:

Revise the C.S.A of the phase conductor or the protective device rating. Also make sure that correction factors are applied correctly.

The screenshot shows the ElectricalOM software interface. On the left is a tree view of a circuit diagram with various loads like 'P1 FRIDGE', 'S1 RING', 'LIGHTS', 'DB-G', 'DB-F', 'P1 A/C', 'P2 DISH WASHER', 'P3 DRIER', 'P5 A/C', 'P1 COOKER', 'P1 FRIDGE', 'S1 RING', 'LIGHTS', and 'LIGHTS 2'. The main panel is titled 'Apply changes' and contains several sub-sections:

- Supply:** MDB
- Load:** kVA/phase (12.01, 11.69, 8.65), Diversity (0.90, 0.90, 0.90), cosφ (1, 1, 1), 3rd Harmonics (%) (0, 0, 0). Voltage drops for L1, L2, and L3 are shown.
- Phase fault:** max I_{sc} (kA) 0.9693, min I_{sc} (kA) 0.4805, I_b (A) 52.2, I_n (A) 60, min I_z (A) 66.67, I_t (A) 58. A warning icon is present next to I_t.
- Earth fault:** I_{ef} (kA) 0.4557, I_a (A) 332.57, Z_e (Ω) 0.46.
- Disconnection time of Fuse (sec):** 1.06 ≤ 8.86
- Conductors withstand duration (sec):** 1.06 ≤ 8.86
- Earth Fault:** I_{ef} (kA) 0.4557, I_a (A) 332.57, Z_e (Ω) 0.46.
- Fuse:** 1.32 ≤ 5, Z_s(Ω) 0.4795, max Z_s(Ω) 0.657.

A warning message is displayed: "The current inequalities are not satisfied. Recommendation: Revise the C.S.A of the phase conductor or the protective device rating." A small image of a cable cross-section is also visible.

Warnings: 1/8 Critical: 2 All Calculations Load Voltage drop Discrimination Other Selected element only Print

Item	Type	Warning
Supply -> MDB	Critical	There are errors in 'MDB'. Please edit the circuit. 1) The current inequalities are not satisfied (I _b =52.2 < I _n = 60, min I _z =66.67 < I _t =58)

Phase Conductor Adiabatic Check

The software checks that the circuit protective device has a disconnection time satisfying the phase conductor adiabatic check.

[See Minimum Phase Fault Current Calculation](#)

Recommendation to resolve the error:

Revise the phase conductor or the protective device. Also make sure the upstream circuits have been set correctly.

Warnings: 1/12 Critical: 4

Item	Type	Warning
MDB -> P5 A/C 2	Critical	There are errors in 'MDB -> P5 A/C 2'. Please edit the circuit. 1) Phase conductor adiabatic check (Disconnection time of MCB (s) > Conductors withstand duration (s))

Busbar Trunking System Short-Circuit Peak Withstand Check

Where a manufacturer specific busbar trunking system is used, the software checks that the short-circuit maximum peak value is not greater than the withstand value given by the manufacturer.


[See Short-Circuit Maximum Peak Value for Busbar Trunking Systems](#)

Recommendation to resolve the error:

Revise the selection of the busbar trunking system. Also make sure the upstream circuits have been set correctly.

Warnings: 1/37 Critical: 13

Item	Type	Warning
Supply -> MDB	Critical	There are errors in 'MDB'. Please edit the circuit. 1) The short-circuit maximum peak value = 27.83kA is greater than the busbar's short-circuit peak withstand = 9.6kA





Ultimate Breaking Capacity of the Circuit's Protective Device Check

The software checks that the ultimate breaking capacity of the circuit's protective device (I_{cu}) is not less than the maximum phase fault current at the starting point.

Recommendation to resolve the error:

Revise the circuit's protective device breaking capacity. Also make sure the upstream circuits have been set correctly.

[See the calculation details](#)



Ultimate Breaking Capacity of the Incomer Protective Device Check

The software checks that the ultimate breaking capacity of the incomer protective device (I_{cu}) is not less than the maximum phase fault current.

Recommendation to resolve the error:

Revise the incomer protective device breaking capacity. Also make sure the upstream circuits have been set correctly.

The screenshot shows the 'Apply changes' dialog box with the 'Circuit protection' tab selected. The 'Overcurrent protection' section is active, showing a 'breaking Capacity' of 10 kA. A red circle highlights this value, and a tooltip explains: 'The Icu : Ultimate Breaking Capacity of the in-circuit protective devices is lower than the maximum phase fault maxisc. Recommendation: Revise the Ultimate Breaking Capacity of the in-circuit protective device'. Below the dialog, a warning message states: 'There are errors in 'MDB'. Please edit the circuit. 1) The ultimate breaking capacity of the in-circuit protective device Icu = 20kA is less than the maximum phase fault maxisc = 10.34kA'.

This screenshot shows a similar warning message: 'There are errors in 'MDB'. Please edit the circuit. 1) The rating of the in-circuit switch/isolator used is less than the design current of the circuit (in-circuit rating) = 40 < I_b(A) = 52.2'. The warning is displayed in a blue bar at the bottom of the software interface.

Rating of the In-circuit Switch/Isolator Check

The software checks that the in-circuit isolation/disconnection device rating is greater than or equal to the design current (I_b).

Recommendation to resolve the error:

Select an in-circuit with rating greater than or equal to the design current value (I_b).

The screenshot displays a detailed circuit schematic on the left and the 'Apply changes' dialog box on the right. In the 'Apply changes' dialog, the 'Isolation/Disconnection' section is active, showing a rating of 40 A. A red circle highlights this value, and a tooltip states: 'The nominal rating of the disconnector/isolator is lower than the I_b. Recommendation: Revise the nominal rating of the disconnector/isolator'. A large red text overlay reads 'Isolation/Disconnection Rating must be greater than Design Current (Ib)'. Below the dialog, a warning message states: 'There are errors in 'MDB'. Please edit the item. 1) The rating of the in-circuit switch/isolator used is less than the design current of the circuit (in-circuit rating) = 40 < I_b(A) = 52.2'.

Item	Type	Warning
Supply -> MDB	Critical	There are errors in 'MDB'. Please edit the item 1) The rating of the incomer switch/isolator used is less than the design current (Incomer rating(A) = 40 < Ib(A)=52.2)

Rating of the Incomer Overcurrent Protective Device Check

The software checks that the rating of the incomer overcurrent protective device is not lower than the design current (I_b).

Recommendation to resolve the error:

Revise the rating of the incomer overcurrent protective device.

The screenshot shows the 'Apply changes' dialog for the 'MDB' element. In the 'Overcurrent protection' section, the 'In (A)' field is set to 40, which is circled in red. A tooltip message states: 'The rating of the incomer protective device is lower than the design current Ib. Recommendation: Revise the rating of the incomer protective device.' The 'Ib (A)' field is also visible, showing a value of 52.2.

Item	Type	Warning
Supply -> MDB	Critical	There are errors in 'MDB'. Please edit the circuit 1) The rating of the incomer overcurrent protective device is lower than the design current Ib

Neutral Conductor Current Carrying Capacity Check

When the engineer chooses to size the neutral conductor separately, in a three-phase + neutral single-core cable, the software checks if the neutral conductor's current carrying capacity is equal to or greater than the calculated neutral current.

Recommendation to resolve the error:

Revise the C.S.A of the neutral conductor or try to reduce the high neutral current due to the high third harmonics current and/or unbalancing of the loads.

The screenshot shows the ElectricalOM software interface. The top menu bar includes 'Schematic', 'Circuit edit', 'Circuit details', 'Discrimination study', 'Reports', 'Plan Design', and 'EAC & EMS Forms'. The main window is titled 'Three-phase 400V and N 230V 50Hz'. On the left, there are sections for 'Supply from' (Supply), 'Description' (MDB), 'Load' (Sub-circuits, Predefined), and 'Voltage Drop' (L1, L2, L3). The 'Neutral current (A)' is highlighted with a red circle and shows a value of 13.96. Below this, there are sections for 'Phase fault' and 'Earth Fault'. On the right, the 'Ph/N Conductor' section is active, showing 'Type' (4D1 Cu), 'Wiring' (3Ph + N), and 'Installation' (Method A No. 1). The 'Parallel conductors' section shows a value of 10.5, which is also circled in red. A warning message at the bottom states: 'The neutral conductor current carrying capacity is less than the calculated neutral current'. A recommendation follows: 'Recommendation: Revise the C.S.A of the neutral conductor or try to reduce the neutral current due to the high 3rd Harmonics current and/or unbalancing of the loads'.

This screenshot shows the warning list in the software. The top bar indicates 'Warnings: 1/9 Critical: 1 All'. The warning list table is as follows:

Item	Type	Warning
Supply -> MDB	Critical	There are errors in 'MDB'. Please edit the circuit. 1) The neutral conductor current carrying capacity is less than the calculated neutral current.

Neutral Current Protective Device Rating Check

The software checks whether the neutral current is over the circuit's protective device rating due to high third harmonics current and/or unbalancing of the loads.

Recommendation to resolve the error:

Revise the protective device rating or try to reduce the high neutral current due to the high third harmonics current and/or unbalancing of the loads.

The screenshot displays the 'Apply changes' dialog box in the ElectricalOM software. The 'Ph/N Conductor' tab is active, showing the configuration for a 4D1 Cu Single-core 70°C PVC non-armoured conductor. The 'Wiring' section is set to '3Ph + N' with a 'Makeup of circuit conductors' of 'Pvc70/S/Cu 3x1Cx2.5mm²/1Cx1mm² N + 1x1.5mm² E'. The 'Installation' section is set to 'All methods'. A warning message is displayed: 'The protective device rating is lower than the neutral current. Recommendation: Revise the protective device rating or reduce the neutral current.' The warning also includes a note: 'Cables in conduit in masonry having a thermal resistivity not greater than 2 Km/W'. The 'Reference method: B' and 'De: Cable diameter' are selected. The 'Conduit' is set to 'Plastic' and 'Light' with a 'Bend set' of 1 and a 'Diameter (mm)' of 32. The 'Length (m)' is 15. The 'C.S.A (mm²) / Rating' is 2.5 / 21A. The 'Parallel conductors' are set to 'Use'. The 'Set the neutral conductor' checkbox is checked. The 'C.S.A (mm²)' is 1. The 'Parallel conductors' checkbox is unchecked. The 'It (A)' is 12. The 'Neutral current(A)' is 20.22. The 'Voltage Drop of this circuit L1' is 2.12 V (0.92%). The 'Voltage Drop of this circuit L2' is 7.02 V (3.05%). The 'Voltage Drop of this circuit L3' is 0 V (0%). The 'Total Load(kVA)' is 15. The 'Phase fault' section shows 'max lsc (kA)' of 1.8521, 'max lsc at starting point (kA)' of 11.98, 'min lsc (kA)' of 0.4733, and 'Ze (Ω)' of 0.02. The 'Earth Fault' section shows 'Ief (kA)' of 0.5806, 'Ia(A)' of 200, and 'Ze (Ω)' of 0.04. The 'Disconnection Time (sec)' is 0.01. The 'Conductors withstand duration (sec)' is 0.37. The 'MCB' section shows 'Maximum' of 5 and 'max Zs(Ω)' of 1.0925. The 'Warnings' section at the bottom shows a critical warning: 'There are errors in 'DB 1'. Please edit the circuit. 1) The current inequalities are not satisfied (Ib=35 < In=20, minIz=20 < It=21). 2) The neutral conductor current carrying capacity is less than the calculated neutral current. 3) The protective device rating is lower than the Neutral Current.'

Motor Starter Overload Setting Check

The software checks that the motor starter overload rating is greater than or equal to the design current (I_b) of the motor circuit.

Recommendation to resolve the error:

Revise the motor starter overload rating to a value greater than or equal to the design current (I_b) of the motor circuit.

The screenshot shows the 'Apply changes' dialog box for a motor starter. The 'Overload rating' is set to 1.0 A, which is circled in red. A warning icon is present next to it. The warning message reads: "The motor starter overload setting must be set to a value equal or greater than the design current (Ib) of the motor circuit." The background shows a project tree with various electrical components like DB-G, DB-F, and various appliances.

This screenshot shows the 'Warnings' list at the bottom of the software interface. It displays a critical warning for 'MDB -> MS' with the message: "There are errors in 'MS'. Please edit the circuit. 1) The motor starter overload setting must be set to a value equal or greater than the design current (Ib) of the motor circuit."

UPS Power Rating Check

The software checks the UPS rating and provides a warning when this is lower than the design current of the circuit.

Recommendation to resolve the error:
Revise the UPS apparent power value.

The screenshot shows the 'Apply changes' dialog box for a UPS. The 'UPS Apparent Power' is set to 10.00 kVA, which is circled in red. A warning icon is present next to it. The warning message reads: "The UPS Power Rating is not adequate. Recommendation: Revise the UPS Rating." The background shows the same project tree as the previous screenshot.

Item	Type	Warning
DB 1 -> UPS	Critical	There are errors in 'UPS'. Please edit the circuit 1) The UPS Power Rating is not adequate (UPS Rating = 14.43 A < I _b = 40)

Transfer Switch Load Rating Check

The software checks the transfer switch load rating and provides a warning when this is lower than the design current of the circuit.

Recommendation to resolve the error:
Revise the transfer switch load rating.


The screenshot shows the software interface with a warning for 'Transfer switch'. The 'Load' is set to 10.00 A, which is circled in red. A tooltip message states: 'The transfer switch rating is not adequate. Recommendation: Revise the transfer switch rating'. The interface also displays various electrical parameters such as voltage drop, total load, and phase fault data.

Item	Type	Warning
DB 1 -> TS	Critical	There are errors in 'TS'. Please edit the circuit 1) The transfer switch load rating is not adequate (Transfer switch load rating = 10 A < I _b = 30)

Source Load Capacity Check

The software checks the active source load capacity and provides a warning when this is lower than the active network's total design current.

Recommendation to resolve the error:
Increase the source load capacity or apply more diversity to the total design current.




Item	Type	Warning
Supply	Critical	The total network design current exceeds the load capacity of the source

Source Earthing Conductor Adiabatic Check

If the engineer has chosen to set the earthing conductor at the source level (the starting point of the installation), the software checks that the earthing conductor has a cross-sectional area satisfying the adiabatic check.

Recommendation to resolve the error:

Revise the earthing conductor.



Warnings: 1/16	Critical: 11	All	Calculations	Load	Voltage drop	Discrimination	Other	Selected element only	Print
Item	Type	Warning							
Supply	Critical	The adiabatic check of earthing conductor in source is not satisfied							

Important

Important warnings should be resolved in good practice but can be left unresolved for the completion of the study. They are warnings about potential hazards to the installation.

[Voltage Drop over the Split Limit Set Check](#)

[Energy Based Discrimination Check](#)

[Discrimination During Overcurrent Check](#)

[Discrimination During Earth Fault Check](#)

[Motor Starting Check](#)

[Service Breaking Capacity of the Circuit Protective Device Check](#)

[Service Breaking Capacity of the Incomers Protective Device Check](#)

[Installation in Conduit Check](#)

[Installation in Trunking Check](#)

[Installation Compliance with Regulations Check](#)

[Harmonic Content in Circuit Check](#)

[Current Carrying Capacity of the Tails Conductor Check](#)

Voltage Drop over the Split Limit Set Check

For distribution circuits there is an option to split the voltage drop limit between the distribution circuit and its final circuits. This split limit is not a regulation requirement but is set by the designer to warn him or her about circuits exceeding the specified voltage drop percentage value, allowing for finer control of the voltage drop across circuits. The software provides a warning when the voltage drop of the circuit is over the split limit set.

Recommendation to resolve the error:

Revise the conductor or set a higher voltage drop split limit for the particular circuit.

The screenshot shows the 'Voltage Drop' tab in the software. On the left, a table lists voltage drops for three phases:

Phase	Voltage Drop (V)	Percentage (%)
L1	0.34	0.15%
L2	0.17	0.08%
L3	0.38	0.17%


Below this table, a red circle highlights the 'Voltage Drop of this circuit L1' row. In the main settings area, the 'Split the voltage drop limit between the distribution circuit and to its connected final circuits' option is selected. The 'Voltage drop limit per phase of the distribution circuit (%)' is set to 0.10, which results in a limit of 0.23 V. This value is also circled in red. A warning message at the bottom states: 'The total voltage drop of 'DB 1' is over the split limit set (0.1% = 0.23V) per phase'.

Energy Based Discrimination Check

When the manufacturer's energy-based discrimination data are available and the fault condition is causing operation of the protective device below 0.1 sec, the checks are performed based on the manufacturer's discrimination tables. The software provides a warning when the discrimination check fails against an up-stream device.

Recommendation to resolve the error:

Revise the protective device.




Discrimination During Overcurrent Check

When the manufacturer's energy-based discrimination data are not available or the fault condition is causing operation of the protective device over 0.1 sec, ElectricalOM performs discrimination checks between the time-amperes curves of the protective devices, where overlapping curves indicate a discrimination problem. The check is made up to the value of the maximum prospective short-circuit current at the downstream protective device.

Recommendation to resolve the error:

Revise the protective device so the curves are not overlapping.



Warnings: 2/4 Critical: 2 All Calculations Load Voltage drop Discrimination Other Selected element only Print

Item	Type	Warning
DB 1 -> Final circuit	Important	The protective device is not suitable for selective use during overcurrent

Incomer Protective Device Discrimination During Overcurrent Check


Discrimination checks are also made for incomer overcurrent protective devices. See [Discrimination During Overcurrent](#).

Discrimination During Earth Fault Check

Where an RCD device has not been installed, the check is performed in the same way as for the overcurrent protective device, but considering the earth fault levels. Otherwise the check is made comparing the RCD curves.

Recommendation to resolve the error:

Revise the protective device so the curves are not overlapping.



Warnings: 2/4 Critical: 2 All Calculations Load Voltage drop Discrimination Other Selected element only Print

Item	Type	Warning
DB 1 -> Final circuit	Important	The protective device is not suitable for selective use during overcurrent
DB 1 -> Final circuit	Important	The protective device is not suitable for selective use during Earth fault

Incomer Protective Device Discrimination During Earth Fault Check

Discrimination checks are also made for incomer RCD devices. See [Discrimination During Earth Fault](#).


Motor Starting Check

Motor circuits require that their protective devices have specific characteristics to avoid inadvertent operation during the motor starting period. The check made is based on the selected protective device and the motor's starting current and starting duration settings. Based on these parameters the motor starting curve is calculated and compared to the protective device curve. Overlapping between the curves indicates inadvertent operation.

Recommendation to resolve the error:

Revise the protective device so the motor and protective device curves are not overlapping.

The screenshot shows the 'Apply changes' dialog box for a motor. The 'Motor Settings' tab is active, showing a warning icon (red exclamation mark) next to the starting current value of 33.93 A. A tooltip message reads: 'Inadvertent operation of protective device may occur caused by high current during the motor starting period. Recommendation: Revise the protective device'. Other settings include: Type: Direct On Line, Usage: General, Motor efficiency: 1.00, Starting current: 6.5 x Ib = 33.93 A, Starting duration: 2.00 sec, and Overload setting: 5.22 A.



Warnings: 1/61 All Calculations Load Voltage drop Discrimination Other Selected element only Print

Item	Type	Warning
DB 1 -> Final circuit	Important	Inadvertent operation of protective device may occur, caused by high current during the motor starting period

Service Breaking Capacity of the Circuit Protective Device Check

The software checks that the service breaking capacity of the protective device (I_{cs}) is not less than the circuit's maximum phase fault current.

Recommendation to resolve the error:

Revise the circuit's protective device I_{cs} . Also make sure the upstream circuits have been set correctly.

The screenshot shows the 'Apply changes' dialog box in ElectricalOM. The 'Breaking Capacity' section is highlighted with a red circle, showing I_{cs} (kA) set to 7.5. A tooltip explains: 'The value of I_{cs} : Service Breaking Capacity of the protective device is lower than the maximum phase fault $maxI_{sc}$. Recommendation: Revise the protective device'. The 'Phase fault' section shows $max I_{sc}$ (kA) as 8.4768. The 'Earth Fault' section shows I_{ef} (kA) as 0.5927 and I_{a} (A) as 400. The 'Warnings' bar at the bottom indicates 1 Critical warning: 'The service breaking capacity of the protective device $I_{cs} = 7.5kA$ is less than the maximum phase fault $maxI_{sc} = 8.48kA$ '.

Service Breaking Capacity of the Incomers Protective Device Check

The software checks that the service breaking capacity of the in-circuit protective device (I_{cs}) is not less than the maximum phase fault current of one of the sub circuits.

Recommendation to resolve the error:
Revise the in-circuit protective device I_{cs} .

The screenshot shows the 'Apply changes' dialog box after a change. The 'Breaking Capacity' section is highlighted with a red circle, showing I_{cs} (kA) set to 6. A tooltip explains: 'The I_{cs} : Service Breaking Capacity of the in-circuit protective devices is lower than the maximum phase fault $maxI_{sc}$ of one of the sub circuits. Recommendation: Revise the Service Breaking Capacity of the in-circuit protective device'. The 'Phase fault' section shows $max I_{sc}$ (kA) as 8.4768. The 'Earth Fault' section shows I_{ef} (kA) as 0.5927 and I_{a} (A) as 500. The 'Warnings' bar at the bottom indicates 1 Critical warning: 'The service breaking capacity of the in-circuit protective device $I_{cs} = 6kA$ is less than the maximum phase fault at one of its sub-circuits $sub-maxI_{sc} = 6.44kA$ '.

Installation in Conduit Check

Where the installation incorporates conduit, a check is made that the conduit is sized to accommodate the makeup of the conductors. *Calculation is based on the IET Guidance Note 1, Appendix A.*

Recommendation to resolve the error:
Revise the conduit size.

The screenshot shows the software interface for a three-phase 400V and N 230V 50Hz installation. The 'Apply changes' panel on the left shows load details for DB 1, including kVA/phase (2.3), Amps/phase (10.0), and Voltage Drop (0.08 V). The main panel shows the 'Ph/N Conductor' configuration for a 4D1 Cu conductor. The 'Installation' method is 'Method B No. 59 - in conduit in a wall'. The 'Conduit Size' is set to 'Plastic' and 'Light', with a 'Diameter (mm)' of 15. A red circle highlights the diameter value, and a warning message states: 'The conduit diameter is not enough. Calculation is based on the IEE Guidance Note 1, Appendix A. Recommendation: Revise the installation method.'

Warnings: 1/1	Important	Calculations	Load	Voltage drop	Discrimination	Other	Selected element only	Print
⊕	DB 1 -> Final circuit	Important					Conduit size is not enough	

Installation in Trunking Check

Where the installation incorporates trunking, a check is made that the trunking is sized to accommodate the makeup of the conductors. *Calculation is based on the IET Guidance Note 1, Appendix A.*

Recommendation to resolve the error:
Revise the trunking size.

The screenshot shows the software interface for a single phase and N 230V 50Hz installation. The 'Apply changes' panel on the left shows load details for DB 1, including Watts of a point (100), Amps/Phase of a point (0.44), and Voltage Drop (0 V). The main panel shows the 'Ph/N Conductor' configuration for a 4D1 Cu conductor. The 'Installation' method is 'Method B No. 7 - in trunking on a wall run vertically'. The 'Trunking' is set to 'Plastic' with a 'Dimension (mm x mm)' of 50x38. A red circle highlights the dimension value, and a warning message states: 'The trunking size is not enough. Calculation is based on the IEE Guidance Note 1, Appendix A. Recommendation: Revise the installation method.'

...	Item	Type	Warning
	DB 1 -> Final circuit	Important	Trunking size is not enough

Installation Compliance with Regulations Check

Installations in wall, floor, or ceiling must comply with the regulations 522.6.202,522.6.203,522.6.204 in BS 7671:2008 (2015).

Recommendation to resolve the error:

Check the **Comply with regulations** box, to declare awareness about the specific regulations.

Schematic | Circuit edit* | Circuit details | Discrimination study | Reports | Plan Design | EAC & EMS Forms | Panel layout

Apply changes | Cancel | Print

Supply from: DB 1 | Description: Final circuit | Active

Load: Kind: Electric motor x 1

Watts of a point: 1200 | Total load: | Amps/Phase of a point: 5.22

cosp: 1.00 | 3rd Harmonic(%): 0.0 | Diversity factor: 1.00

Voltage Drop of this circuit L1: 2.01 V (0.87%) | Total kVA: 1.2 | Voltage Drop of this circuit L2: 0 V (0%) | Amperes: 5.22 | Voltage Drop of this circuit L3: 0 V (0%)

Ib (A): 5.22 ≤ In (A): 6 | min Iz (A): 5.22 ≤ It (A): 14.5

Z1(Ω): 0.2175 | Z2(Ω): 0.33

Phase fault: max Isc (kA): 0.5311 | max Isc at starting point(kA): 3.2243 | min Isc (kA): 0.4356 | Ze (Ω): 0.08

Disconnection time of MCB (sec): 0.01 ≤ Conductors withstand duration (sec): 0.16

Earth Fault: Ief (kA): 0.2327 | Ie(A): 60 | Ze (Ω): 0.39

Disconnection time (sec): MCB: 0.01 ≤ Maximum: 0.4 | Zs(Ω): 0.9391 ≤ max Zs(Ω): 3.6417

Kind: 4D1 | Cu | Single-core 70°C PVC non-armoured

Filter list: Cu: All insulations | Al: All kinds | Make up of circuit conductors: Pvc70/S/Cu | 2x1Cx1.5mm² + 1x1mm² E

Options: Flexible

Installation: Category: All methods | Method: Method A No. 1 - In conduit in a thermally insulated wall

Description of the installation method: Cables in conduit in a thermally insulating wall with an inner skin having a thermal conductance of not less than 10 W/m²K

Reference method: A | De: Cable diameter

Comply with regulations: 522.6.202 522.6.203 522.6.204

Conduit: Plastic | Size: Light | Length (m): 15 | C.S.A (mm²) / Rating: 1.5 | 14 A | Parallel conductors: Use

The installation method does not comply with the regulations. Recommendation: Check if installation method complies with the regulations

Regulations information BS 7671:2008 + A3:2015

Reg. 522.6.202 | Reg. 522.6.203 | Reg. 522.6.204

A cable concealed in a wall or partition at a depth of less than 50 mm from a surface of the wall or partition shall:

(i) be installed in a zone within 150 mm from the top of the wall or partition or within 150 mm of an angle formed by two adjoining walls or partitions. Where the cable is connected to a point, accessory or switchgear on any surface of the wall or partition, the cable may be installed in a zone either horizontally or vertically, to the point, accessory or switchgear. Where the location of the accessory, point or switchgear can be determined from the reverse side, a zone formed on one side of a wall of 100 mm thickness or less or partition of 100 mm thickness or less extends to the reverse side, or

(ii) comply with Regulation 522.6.204

Where indent (i) but not indent (ii) applies, the cable shall be provided with additional protection by means of an RCD having the characteristics specified in Regulation 415.1.1.

(i)

Zone 522.6.202

Wall section

Room floor

Room floor

+ RCD 30mA Instant (≤ 40ms @ 5xIΔn)

Warnings: 1/63 | All | Calculations | Load | Voltage drop | Discrimination | Other | Selected element only | Print

Item	Type	Warning
DB 1 -> Final circuit	Important	The installation method does not comply with regulations: 522.6.202 522.6.203 522.6.204

Harmonic Content in Circuit Check

When high harmonic content is present in the circuit, the software checks that overcurrent protection is provided for the neutral conductor (BS 7671 Reg. 431.2.3).

Recommendation to resolve the error:

Use a 4 pole CPD.

The screenshot shows the ElectricalOM software interface. The 'Circuit protection' tab is active, showing an 'Adjustable MCCB 35kA' device with 'Poles' set to 3. A red circle highlights the 'Poles' dropdown menu, which has options 3, 3, and 4. A warning message at the bottom states: 'The overcurrent CPD should provide protection to the neutral conductor. A 4pole CPD is recommended'. The interface also displays various electrical parameters such as kVA/phase, Amps/phase, and voltage drops.

Current Carrying Capacity of the Tails Conductor Check

If the engineer chooses to set the tails conductor and use the protection device from the supplier, the software checks that the current carrying capacity of the tails conductor agrees with the rating of the supplier's protective device.

Recommendation to resolve the error:

Revise the tails conductor so that $I_t \geq I_n$.

ElectricalOM - Edit Source *

Description

Source properties | Earthing | Premises & Diversity | **Other**

Tails conductor (between the meter and the first protective device) Use **!**

Cable

Installation C.S.A (mm²) Parallel Length

It (A) R (Ω) X (Ω) Z (Ω)

Backup protection from supplier Use

Manufacturer

Type

Device

In(A) Poles

Building bonding conductor C.S.A (mm²) Use

OK Cancel Three-phase: 400V , 230V 3Ph + N

Warnings: 1/83 **!** Critical: 1 Important Calculations Load Voltage drop Discrimination Other Selected element only Print

Item	Type	Warning
Supply	Important	The current carrying capacity of the tails conductor is not enough

Simple

Simple warnings have to do with minor issues that won't cause serious problems to the project and that do not have to be resolved, but that could indirectly bring about more serious issues in the later stages of implementation.

[Load Balance Check](#)

[Power Factor Correction Unit Usage Check](#)

[Existing Installation - Exclude from the Checks](#)

[Inactive Circuit Check](#)

Load Balance Check

The software provides a warning if the load in the distribution circuit is not balanced.

Recommendation to resolve the error:

Review the allocation of loads in each phase.

[See more details here](#)

Properties Symbols Load Volt drop

DB 1

Connected load

	kVA	Amperes
Phase 1	0.2	0.9
Phase 2	0.2	0.9
Phase 3	0.1	0.4
Total	0.5	

Diversified load

	kVA	Amperes
Phase 1	0.2	0.9
Phase 2	0.2	0.9
Phase 3	0.1	0.4
Total	0.5	

Diversified + Spare load

	kVA	Amperes
Phase 1	0.2	0.9
Phase 2	0.2	0.9
Phase 3	0.1	0.4
Total	0.5	

Warnings: 1/83 Critical: 1 Simple Calculations Load Voltage drop Discrimination Other Selected element only Print



Item	Type	Warning
DB 1 -> DB 1	Simple	The load of 'DB 1' is not balanced. It is recommended to review the allocation of loads in each phase

Power Factor Correction Unit Usage Check

When the calculated power factor ($\cos \phi$) at the main distribution circuit is calculated to be less than 0.85, the software notifies the designer that it is appropriate to install a power factor correction unit.

Recommendation to resolve the error:

Install a power factor correction unit to correct the total power factor ($\cos \phi$).



Existing Installation Warning

If the user sets a distribution circuit as an existing installation then no checks are performed. A warning indicates that this distribution circuit has been excluded from calculations and checks.

The screenshot shows the 'Apply changes' dialog box in the software. The 'Existing installation - Excluded from the checks' checkbox is checked and circled in red. The dialog is divided into several sections: 'Supply from' (DB 1), 'Load' (kVA/phase: 2.3, Amps/phase: 10.0, Spare(%): 0), 'Voltage Drop' (L1, L2, L3), 'Phase fault' (max lsc, min lsc, Ze), 'Earth Fault' (Ief, Ia, Ze), and 'Test results' (lsc, Ze, Re, R1+R2, R2, Zs, Insulation resistance). The 'Test results' section shows values for lsc (9.07 kA), Ze (0.04 Ω), Re (0.03 Ω), R1+R2 (0.34 Ω), R2 (0.33 Ω), and Zs (0.3747 Ω).

The screenshot shows the 'Warnings' section of the software. It displays a warning for 'Supply -> DB 1' with the message 'This is an existing installation. No checks are performed for this circuit'. The warning is categorized as 'Simple'.

Inactive Circuit Warning

When a circuit is marked as inactive, the software warns the engineer about this state. Inactive circuits are excluded from the load summations, calculations and checks. This functionality allows the designer to model the on/off state of a circuit for a particular scenario.

The screenshot shows the 'Apply changes' dialog box in the software. The 'Inactive' checkbox is checked and circled in red. The dialog is divided into several sections: 'Supply from' (DB 1), 'Load' (Kind: Lighting, Watts of a point: 100, Amps/Phase of a point: 0.44), 'Voltage Drop' (L1, L2, L3), 'Phase fault' (max lsc, min lsc, Ze), 'Earth Fault' (Ief, Ia, Ze), and 'Installation' (Category: All methods, Method: Method B No. 4, Description of the installation method: Non-sheathed cables in conduit on a wooden or masonry wall or spaced less than 0.3 x conduit diameter from it). The 'Installation' section also shows a diagram of a cable in a conduit and various input fields for conduit type, size, length, and C.S.A.

Warnings: 1/1		All	Calculations	Load	Voltage drop	Discrimination	Other	Selected element only	Print
...	Item	Type	Warning						
	DB 1 -> Final circuit	Simple	The circuit 'DB 1->Final circuit' is not active. It does not take part in the calculations and checks						